

PARTS LIST

GASOLINE BLOWER/VACUUM

BL3300

Art# 030225




Use only NAKAYAMA genuine parts as specified in the parts list for repair or replacement.
Check if your machine meets the applicable models listed below.
The contents described in the parts list may change due to improvement.




APPLICABLE:

June 2020

BL3300 Fig.1



No#	Code	Description (EN)	QTY	Notes
1	0302251001	SCREW	1	
2	0302251002	OUTSIDE COVER	1	
3	0302251003	FILTER NET	1	
4	0302251004	SCREW 3x 8	1	
5	0302251005	M5 x 60	2	
6	0302251006	Choke	1	
7	0302251007	INSIDE COVER	1	
8	0302251008	Choke HANDLE	1	
9	0302251009	CARBURETOR	1	
10	0302251010	GASKET	1	
11	0302251011	SCREW M5 x 25	1	
12	0302251012	ADMITTING PIPE	1	
13	0302251013	GASKET	1	
14	0302251014	OIL SEAL	2	
15	0302251015	SCREW M5 x12	1	
16	0302251016	CRANK CASE GASKET	1	
17	0302251017	PIN B4*8	2	
18	0302251018	BEARING 6001-P6	2	
19	0302251019	NEEDLE BEARING	1	
20	0302251020	CRANK SHAFT COMP	1	
21	0302251021	KEY	1	
22	0302251022	PISTON	1	
23	0302251023	PISTON PIN	1	
24	0302251024	PISTON PIN CIRCLIP	2	
25	0302251025	PISTON RING	2	
26	0302251026	GASKET	1	
27	0302251027	CYLINDER	1	
28	0302251028	M5x16	4	
29	0302251029	PLUG	1	
30	0302251030	MUFFLER GASKET	1	
31	0302251031	MUFFLER	1	
32	0302251032	MUFFLER COVER	1	
33	0302251033	SCREW M5 x 55	1	
34	0302251034	CAP	1	
35	0302251035	SPRING	1	
36	0302251036	6*60 PIPE	1	
37	0302251037	IGNITION COIL	1	
38	0302251038	INSIDE COVER ASSEMBLAGE	1	
39	0302251039	SCREW M6 x16	2	
40	0302251040	START REEL	1	
41	0302251041	NUT 8	1	
42	0302251042	WASHER 8	1	
43	0302251043	WASHER 8	1	
44	0302251044	FLY WHEEL	1	
45	0302251045	SCREW M4 x 20	2	
46	0302251046	SCREW M5 x 20	3	
47	0302251047	REAR HALF CRANK CASE	1	
48	0302251048	GASKET	1	
49	0302251049	IGNITION COIL COMP	1	
50	0302251050	CYLINDER-PISTON ASSY	1	



No#	Code	Description (EN)	QTY	Notes
1	0302252001	PIPE (2)	1	
2	0302252002	PIPE (1)	1	
3	0302252003	SCREW M5 x10	1	
4	0302252004	SCREW M5 x16	1	
5	0302252005	WASHER $\Phi 5$	1	
6	0302252006	PROTECTION	1	
7	0302252007	SPING SCREW	1	
8	0302252008	SPING	1	
9	0302252009	SCREW M5 x19	3	
10	0302252010	NUT M8 x1 LH	1	
11	0302252011	COMMINUTE BOARD	1	
12	0302252012	SCREW M5 x 22	1	
13	0302252013	IMPELLER	1	
14	0302252014	HANDLE COVER (2)	1	
15	0302252015	STOP SWITCH	1	
16	0302252016	FRONT VALUTE CASE	1	
17	0302252017	HANDLE	1	
18	0302252018	STOP WIRE	1	
19	0302252019	CONTROL HANDLE	1	
20	0302252020	FUEL THROTTLE	1	
21	0302252021	WASHER	1	
22	0302252022	NUT M5	1	
23	0302252023	HANDLE	1	
24	0302252024	WASHER	1	
25	0302252025	CONTROL HANDLE	1	
26	0302252026	SCREW M5 x 20	1	
27	0302252027	HANDLE COVER(1)	1	
28	0302252028	FUEL TANK	1	
29	0302252029	FILTER	1	
30	0302252030	FUEL PIPE	1	
31	0302252031	FUEL PIPE	1	
32	0302252032	PLUG	1	
33	0302252033	BACK VALUTE CASE	1	
34	0302252034	SCREW M5 x16	1	
39	0302252039	FUEL TANK LID ASSEMBLAGE	1	
40	0302252040	FUEL TANK ASSEMBLAGE	1	
41	0302252041	SCREW M5 x10	1	
42	0302252042	WASHER $\Phi 5$	1	
43	0302252043	ROPE	1	
44	0302252044	STARTER ROPE REEL	1	
45	0302252045	RECOIL SPRING	1	
46	0302252046	STARTER BODY	1	
47	0302252047	STARTER HANDLE	1	
48	0302252048	STARTER	1	
49	0302252049	SCREW M5 x12	3	
50	0302252050	COLLECTING BAG	1	
51	0302252051	COLLECTING PIPE	1	
52	0302252052	PIPE	1	
53	0302252053	PIPE	1	
54	0302252054	BAFFLE	2	