


POS.	CODE	DESCRIPTION	QTY
1	A04529	CUTTING DECK	1
2	A04530	CUTTING BLADE	1
3	A04503	BLADE FLANGE	1
4	A04479	BLADE BOLT	1
5	A04535	CONNECTING BAR	1
6	A04491	HEIGHT ADJUSTMENT HANDLE	1
7	A04492	CONNECTING BAR SPRING	1
8	A04493	HEIGHT ADJUSTMENT BOARD	1
9	A04490	GRASS BAG FRAME	1
10	A04515	GRASS BAG	1
11	A04514	REAR FLAP	1
12	A04488	FLAP SPRING	1
13	A04489	FLAP AXLE	1
14	A04485	UPPER HANDLE	1
15	A04499	LOWER HANDLE	1
16	A04494	LOWER HANDLE FIXER, LEFT	1
17	A04495	LOWER HANDLE FIXER, RIGHT	1
18	A04517	FLASH NUT	2
19	A04476	BOLT M8x50	2
20	A04522	SOFT GRIP	1
21	A04531	BRAKE CABLE	1
22	A04532	DRIVE CABLE	1
23	A04533	DRIVE LEVER	1
24	A04504	BRAKE LEVER	1
25	A04484	CABLE CLAMP	1
26	A04536	FRONT AXLE	1
27	A04537	REAR AXLE	1

POS.	CODE	DESCRIPTION	QTY
28	A04553	LEFT REAR AXLE BUSH	1
29	A04549	CYLINDRICAL REAR AXLE BUSH	1
30	A04527	REAR AXLE PRESSURE PLATE	2
31	A04539	GEARBOX	1
32	A04528	GEARBOX TENSIONER SPRING	1
33	A04555	BELT COVER	1
34	A04543	BELT A-686	1
35	A04546	FRONT BELT PULLEY	1
36	A04545	REAR BELT PULLEY	1
37	A04523	CYLINDRICAL PIN	2
38	A04513	FRONT AXLE BUSH	2
39	A04502	FRONT AXLE SPRING	2
40	A04534	GEARBOX CLIP	1
41	A04550	REAR AXLE BUSH	2
42	A04633	DRIVING GEAR, LEFT	1
43	A04538	DRIVING GEAR, RIGHT	1
44	A04552	DUST-PROOF COVER, RIGHT	1
45	A04554	DUST-PROOF COVER, LEFT	1
46	A04551	WHEEL 210Ø	2
47	A04548	WHEEL COVER 210Ø	2
48	A04518	WHEEL175Ø	2
49	A04519	WHEEL INNER COVER 175Ø	2
50	A04547	WHEEL COVER 175Ø	2
51	A04501	START HOOK	1
52	A04506	125cc ENGINE	1
53	A04509	WHEEL NUT M8	4
54	A04481	WHEEL WASHER	4

POS.	CODE	DESCRIPTION	QTY
55	A04511	CLIP	2
56	A04512	PIN	2
57	A04524	PIN AXLE WASHER	1
58	A04526	WASHER	1
59	A04745	NUT M5	3
60	A04507	BOLT M5x12	3
61	A04635	BOLT M6x14	2
62	A04474	NUT M6	2
63	A04510	NUT M8	8
64	A04477	BOLT M8x16	8
65	A04478	WASHER	6
66	A04482	BOLT M8x35	3
67	A04475	WASHER	1
68	A04480	WASHER	1
69	A04540	SCREW ST6x16F	8
70	A04525	WASHER	6
71	A04544	WOODRUFF KEY	1
72	A04541	DOWEL PIN	1
73	A04542	DOWEL PIN	2
74	A04638	SPRING WASHER	2
75	A04607	NUT M6	1
76	A04473	SCREW M6x40	1
77	A04718	CABLE CLIP	1



POS.	CODE	DESCRIPTION	QTY
1	A04859	CRANKCASE	1
2	A04860	SPEED SWING	1
3	A04861	SPEED ADJUSTMENT ROD GASKET	1
4	A04862	SPEED SWING LOCK CLIP	1
5	A04863	PAD OIL SEAL	1
6	A04864	OIL SEAL	1
7	A04865	OIL SEAL	1
8	A04866	INTAKE VALVE	1
9	A04867	EXHAUST VALVE	1
10	A04868	VALVE SPRING	2
11	A04869	SPRING SEAT, INTAKE VALVE	2
12	A04870	SEAL, VALVE STEM	1
13	A04871	ROCKER ASS	2
14	A04872	CRANKCASE COVER	1
15	A04873	OIL RULER ASS	1
16	A04874	GOVERNOR KIT	1
17	A04875	CRANKSHAFT	1
18	A04876	TIMING GEAR	1
19	A04877	CAMSHAFT	1
20	A04878	CRANKSHAFT WASHER	1
21	A04879	CONNECTING ROD ASS.	1
22	A04946	PISTON	1
23	A04881	PISTON RING	1
24	A04882	PISTON PIN	1
25	A04883	CLIP, PISTON PIN	2
26	A04884	LIFTER	2
27	A04885	ROD, PUSH	2
28	A04886	PIN, DOWEL CYLINDER HEAD	2
29	A04887	PIN, DOWEL CRANKCASE COVER	2
30	A04888	PACKING, HEAD COVER	1
31	A04889	COVER COMP, HEAD	1
32	A04890	FLYWHEEL ASS.	1
33	A04891	FLYWHEEL NUT	1
34	A04892	IGNITER ASSY	1
35	A04893	IGNITER DOUBLE-HEADED BOLT	1
36	A04894	START COVER DOUBLE HEAD BOLT	2
37	A04895	WIND BOARD	1
38	A04896	VALVE, BREATHER CHAMBER	1
39	A04897	OIL STRAINER	1
40	A04898	OIL RETURN CHAMBER GASKET	1

POS.	CODE	DESCRIPTION	QTY
41	A04899	OIL RECOVERY CHAMBER COVER	1
42	A04900	FLYWHEEL BRAKE	1
43	A04901	SPRING, IDLE CONTROLLER	1
44	A04902	DOUBLE HEADED BOLT INTAKE	2
45	A04903	GASKET, INSULATOR	1
46	A04904	CARBURETOR JOINT	1
47	A04905	GASKET, CARBURETOR	1
48	A04906	CARBURETOR	1
49	A04907	AIR FILTER SEALING PAD	1
50	A04908	OIL EXHAUST PIPE	1
51	A04909	AIR CLEANER ASS.	1
52	A04910	MUFFLER ASSY	1
53	A04911	MUFFLER COVER	1
54	A04912	SPEED ADJUSTMENT ARM ASS.	1
55	A04913	THROTTLE LEVER	1
56	A04914	MICRO SPEED REGULATING SPRING	1
57	A04915	SPEED CONTROLLER	1
58	A04916	RESET SPRING	1
59	A04917	FUEL TANK ASS	1
60	A04918	STARTER ASS. RECOIL	1
61	A04919	START COVER	1
62	A04920	FUEL TUBE	1
63	A04921	ROCKER PIN	2
64	A04922	BOLT, FLANGE (M6×12)	13
65	A04923	BOLT, FLANGE (M6×18)	10
66	A04924	BOLT, FLANGE (M6×25)	1
67	A04926	CROSS SLOT SMALL DISC HEAD SCREW	1
68	A04927	CYLINDER HEAD BOLTS	2
69	A04928	CYLINDER HEAD DOUBLE HEAD SCREW	2
70	A04929	GASKET, CYLINDER	1
71	A04930	HEAD COMP, CYLINDER	1
72	A04931	PLUG, SPARK	1
73	A04932	BOLT, NUT (M8)	2
74	A04933	BOLT, NUT (M6)	6
75	A04934	BOLT, FLANGE (M6×40)	1
77	A04935	BELT TUBING CLIP Ø11	1
78	A04936	BELT TUBING CLIP Ø10.5	1
79	A04937	BOLT, FLANGE (M6×12)	2

POS.	CODE	DESCRIPTION	QTY
80	A04938	FLYWHEEL FAN	1
81	A04939	START-UP-SET	1
82	A04940	IGNITER SUPPORT	1
83	A04941	BOLT, FLANGE (M5×10)	4
84	A04942	FLAT WASHER Ø6	1
85	A04943	COVER	1
86	A04944	DOUBLE HEAD BOLT	1
87	A04945	COVER MOUNTAIN PLATE	1
89	A04925	FUEL TANK CAP	1
90	A04947	FUEL TANK	1
91	A04948	FILTER	1
92	A04949	AIR FILTER BASE	1
93	A04950	AIR FILTER ELEMENT	1
94	A04951	AIR FILTER COVER	1