




POS.	CODE	DESCRIPTION	QTY
1	A02841	FRONT HOUSING	1
2	A02842	DETERGENT VALVE	1
3	A02843	MOTOR ASSEMBLY	1
4	A02844	REAR HOUSING	1
5	A02845	SWITCH BOX	1
6	A02846	WHEEL ASSEMBLY	1
7	A02847	HANDLE	1
8	A02848	HAND CRANK	1
9	A02849	REEL BASE	1
10	A02850	HOSE REEL	1
11	A02798	PRESSURE HOSE	1
12	A02851	DETERGENT BOTTLE	1
13	43604	HIGH PRESSURE HOSE 8M	1
14	A02853	POWER CORD	1
15	41926	LANCE ROTOR POWER	1
16	41896	GUN	1
17	41925	TURBO LANCE	1



POS.	CODE	DESCRIPTION	QTY
1	A02854	INDUCTIVE MOTOR COVER	1
2	A02855	MOTOR PUMP	1
3	A02856	DAMPING RUBBER	2
4	A02857	SCREW	2
5	A02858	PUMP BASE	1
6	A02859	OUT DETERGENT TUBE	1



POS.	CODE	DESCRIPTION	QTY
1	A02860	CIRCLIP	1
2	A02861	FAN (WITH THE CIRCLIP)	1
3	A02862	MOTOR	1
4	A02863	THRUST BEARING	1
5	A02864	WOBBLE PLATE FAM	1
6	A02865	KEY	1
7	A02866	THRUST BEARING	1
8	A02867	WASHER	1
9	A02868	SPRING WASHER	1
10	A02869	SCREW	1
11	A02870	SCREW	4
12	A02871	SPRING WASHER	4
13	A02872	PUMP HEAD ASSEMBLY	1
14	A02873	PUMP ASSEMBLY	1
15	A02874	BYPASS VALVE PLUG	1
16	A02875	O-RING	2
17	A02876	O-RING	1
18	A02877	SPLIT WASHER	1
19	A02878	BYPASS VALVE	1
20	A02879	PLUG	1
21	A02880	O RING	1
22	A02881	VALVE PLUG (WITH O-RING)	3



POS.	CODE	DESCRIPTION	QTY
23	A02882	O RING	3
24	A02883	SUCTION NIPPLE	1
25	A02884	INLET TUBE	1
26	A02885	SCREW	1
27	A02886	VALVE PLUG	1
28	A02887	PUMP HEAD	1
29	A02888	OUTLET TUBE ASSY	1
30	A02889	WATER SEAL (3 PCS)	1
31	A02890	SEALING STOP RING (3 PCS)	1
32	A02891	O RING (3 PCS)	1
33	A02892	WATER SEALING SUPPORT (3 PCS)	1
34	A02893	WATER SEALING VICE (3 PCS)	1
35	A02894	CHECK VALVE ASSY (3 PCS)	2
36	A02895	O RING	1
37	A02896	OIL SEALING BRACKET (3 PCS)	1
38	A02897	OIL SEALING (3 PCS)	1
39	A02898	PISTON GUIDER	1
40	A02899	PISTON GUIDER ASSEMBLY	1
41	A02900	PISTON (3 PCS)	1
42	A02901	SCREW	2
43	A02902	TSS	1