




POS.	CODE	DESCRIPTION	QTY
34	A04154	SCREW M5X14	2
68	A03929	SCREW M5X20	4
80	A04194	EYELET-CARBURETOR	1
81	A04195	INTAKE	1
82	A03934	SPARK PLUG	1
83	A04196	INTAKE GASKET	1
84	A04197	CYLINDER 43,5mm	1
85	A04198	SCREW M5X87	2
86	A04199	GASKET-MUFFLER	1
87	A04200	MUFFLER	1
88	A04201	SCREW M5X10	2
89	A04202	SHIELD-MUFFLER	1
90	A04203	SCREW	1
91	A04204	GASKET-CYLINDER	1
92	A04358	RING-PISTON	2
93	A04359	PIN-PISTON	1
94	A04360	PISTON 43,5mm	1
95	A04447	RING -SNAP	2
96	A04205	BEARING-NEEDLE	1
97	A04206	CRANK SHAFT-CONROD ASSY	1
98	A04207	WASHER-SPACER PISTON	2
99	A03922	KEY-FLYWHEEL	1




POS.	CODE	DESCRIPTION	QTY
4	A04129	FUEL LINKER	1
9	A04134	PLUG-PAD	3
11	A04271	SCREW ST4.8X16	1
34	A04154	SCREW M5X14	2
46	A04271	SCREW ST4.8X16	3
47	A04165	PAD-RUBBER CUSHIONING (LOWER)	3
48	A04166	CHOKE KNOB	1
49	A04167	CHOKE KNOB COVER	1
50	A04168	CHOKE KNOB PLATE	1
52	A04169	RIGHT CRANKCASE	1
53	A04170	GASKET-RUBBER	1
54	A04171	BEARING-BALL 6206	2
56	A04173	SEAL OIL	1
68	A03929	SCREW M5X20	1
69	A04185	CHAIN CATCHER	1
70	A04186	RING-PLASTIC	1
71	A04187	SPRING-DAMPING	1
72	A04188	SCREW M4X10	1
73	A04189	PLATE-BAR	1
74	A04190	PAD RUGHT	1
75	A04093	STUD-BAR	2
76	A03977	SPIKE	1
77	A04191	AERATE SPIGOT SPONGE	1
78	A04192	AERATE SPIGOT RING -SNAP	1
79	A04193	AERATE SPIGOT	1
100	A04208	PIN	3




POS.	CODE	DESCRIPTION	QTY
101	A04209	GASKET-CRANK CASE	1
102	A04210	HOSE-PULSE RING-SNAP	2
103	A04211	HOSE OIL JOINT	1
104	A04212	HOSE OIL	1
105	A04213	WIRE-SWITCH	1
106	A04214	ELECTRONIC IGNITION	1
107	A03929	SCREW M5X20	2
108	A04215	SCREW M5X25	2
109	A04216	SCREW M5X30	3
110	A04217	GASAKE-FUEL CAP	1
111	A04218	OIL CAP	1
SET 1 (4+110+111)	A12565	OIL CAP ASSEMBLY	1
112	A04219	SNAP RING	1
113	A04220	SEAL OIL 15X35X5	1
114	A04221	PLATE	1
115	A04222	SCREW M4X6	2
116	A04223	FLY-WHEEL ASSEMBLY	1
117	A03926	SCREW	1
119	A04225	LEFT CRANKCASE	1




POS.	CODE	DESCRIPTION	QTY
1	A04127	SCREW ST4.8*19	1
2	A04128	OIL TANK	1
3	A03997	ON/OFF SWITCH	1
4	A04129	FUEL LINKER	1
5	A04130	FUEL GASKET	1
6	A04131	OIL- CAP	1
SET 2 (4-6)	A12564	FUEL CAP ASSEMBLY	1
7	A04132	PAD-RUBBER CUSHIONING	1
8	A04133	HETEROMORPHISM SCREW	2
9	A04134	PLUG-PAD	1
10	A04135	BUMPER-RUBBER(FRONT)	1
11	A04271	SCREW ST4.8*16	4
12	A04136	HANDLE-FRONT	1
13	A04137	LEVER-SAFETY TRIGGER	1
14	A04000	SPRING-TRIGGER	1
15	A04138	TRIGGER	1
16	A04049	PIN	1
17	A04139	PAD-RUBBER	1
18	A04140	PLUG-PAD	1
19	A04141	COVER-REAR HANDLE	1
20	A04142	OIL RETURN PIPE	1
21	A03980	BALANCER	1
22	A04143	OIL FILTER	1
23	A04144	HOSE-FUEL	1
51	A03965	OIL PRIMER	1
118	A04224	OIL RETURN PIPE	1




POS.	CODE	DESCRIPTION	QTY
24	A04082	HOSE- FUEL SPRING	1
25	A04145	HOSE-OIL	1
26	A04146	PAD-RUBBER CUSHIONING (LOWER)	1
27	A04147	SCREW M5X50	2
28+29	A04238	AIR FILTER BASE	1
30	A04150	ROD-THROTTLE	1
31	A04151	AIR DEFLECTOR PLATE	1
32	A04152	SCREW ST3.0X14	2
33	A04153	COVER - TOP	1
34	A04154	SCREW M5X14	4
35	A03937	SCREW TX M5x12	3
36	A04240	AIR FILTER GAKET	1
37	A04239	FILTER-AIR	1
38	A04242	AIR FILTER SCREW	1
39	A04158	SNAP AIR FILTER COVER	2
40	A04159	AIR FILTER COVER	1
41	A04160	CABURATOR	1
42	A04161	FLANGE-CARBURETOR	1
43	A04162	SUPPORT CARBURETOR HEAT INSULATION GASKET	1
44	A04163	SUPPORT CARBURETOR	1
45	A04164	SUPPORT CARBURETOR PLATE	1
166	A04014	GASKET KNOB	1




POS.	CODE	DESCRIPTION	QTY
55	A04172	OIL FILTER	1
57	A04174	SEAL FOAM	1
58	A04175	HOSE OIL INPUT	1
59	A04176	OIL PUMP	1
60	A04177	CLUTCH ASSY	1
61	A04178	WASHER-CLUTCH	1
62	A04179	DRUM-CLUTCH	1
63	A04180	BEARING-NEEDLE CONROD	1
64	A04181	GEAR-WORM	1
65	A04182	SCREW M4X12	4
66	A04183	COVER-OIL PUMP	1
67	A04184	CONNECTOR-OIL OUTLET	1
165	A04230	SPROKET	1



POS.	CODE	DESCRIPTION	QTY
SET 3	A12562	STARTER ASSEMBLY	1
34	A04154	SCREW M5X14	4
46	A04271	SCREW ST4.8X16	1
148	A04226	BAFFLER-FAN	1
149	A04389	GASKET	1
150	A04390	STARTER PULLEY COVER	1
151	A04391	SPRING-STARTER	1
152	A04392	STARTER PULLEY	1
153	A04393	BACK SPRING-STARTER COVER	1
SET 4 (153+154)	A04320	SPRING-STARTER	1
155	A04395	HOUSING-STARTER	1
156	A04396	ROPE-STARTER	1
157	A04397	HANDEL-STARTER	1
158	A04398	HANDLE-ATARTER COVER	1



POS.	CODE	DESCRIPTION	QTY
SET 5	A12563	BRAKE COVER ASSEMBLY	1
74	A04190	PAD RUGHT	1
120	A04362	RING-SNAP	1
121	A04363	LEVER-CHAIN BRAKE	1
122	A04364	PIN	1
123	A04365	LEVERAGE-BRAKE (MAIN)	1
124	A04366	PIN	2
125	A04367	SCREW	2
126	A04368	LEVERAGE-BRAKE (ASSISTANT)	1
127	A04369	BUMPER-RUBBER	1
128	A04370	BRAKE HOUSING	1
129	A04371	DUST BOARD	1
130	A04372	SPRING-ACTUATION	1
131	A04373	SPRING-ACTUATION	1
132	A04374	BAND-BRAKE	1
133	A04375	COVER BRAKE	1
134	A04376	SCREW ST4.2X9.5	5
135	A04377	PLATE-BAR	1
136	A04378	RING-SNAP	2
137	A04379	GASKET	2
138	A04380	PLATE-BRAKE	1
139	A04381	WASHER-RUBBER	1
140	A04382	PLATE-BRAKE	1
141+142	A04383	TOOTH-CHAIN ADJUSTING	1
143	A04385	SPRING-BRAKE LEVER	1
144	A04386	SPROCKET-CHAIN ADJUSTING	1
145	A04387	BUSHING	1
146	A04388	PIN-LEVER	1
147	A03947	PIN	1



POS.	CODE	DESCRIPTION	QTY
159	A04227	BAR PROTECTOR	1
160	*	SAW CHAIN 0.325"-1,5mm-72	1
161	*	GUIDE BAR 45cm-0.325" - 1.5mm	1
162	A04026	SCREWDRIVER	1
163	A04025	PLUG WRENCH	1
164	A04024	ALLEN 4	1

* MORE DETAILS TO OUR CATALOGUE