




POS.	CODE	DESCRIPTION	QTY
43	A04244	SCREW M5X14	2
65	A03934	SPARK PLUG	1
66	A04194	EYELET-CARBURETOR	1
67	A03943	SCREW M5X14	2
68	A04195	BOOT - INTAKE	1
69	A04196	GASKET - INTAKE	1
70	A04204	GASKET-CYLINDER	1
71	A04447	RING - SNAP	2
72	A04448	PIN-PISTON	1
73	A04449	RING-PISTON	2
74	A04450	PISTON 46mm	1
75	A04247	WASHER-SPACER PISTON	2
76	A04205	BEARING-NEEDLE CONROD	1
77	A04267	CRANK SHAFT-CONROD	1
95	A03929	SOKET HEAD CAP SCREW M5X20	4
102	A03922	KEY-FLYWHEEL	1
103	A04203	NUT M5	2
104	A04202	SHIELD-MUFFLER	1
105	A04200	MUFFLER	1
106	A04199	GASKET-MUFFLER	1
107	A04198	COACH BOLT	2
108	A04269	CYLINDER 46mm	1




POS.	CODE	DESCRIPTION	QTY
21	A04129	FUEL PAT	1
23	A04271	CROSS RECESSED PAN HEAD SCREW	3
24	A04140	PLUG-PAD (SMALL)	3
55	A04173	OIL SEAL	1
56	A04171	BEARING-NEEDLE 6202	2
57	A04168	CHOKE KNOB DAMPING SEAT	1
58	A04167	CHOKE KNOB DAMPING COVER	1
59	A04166	CHOKE KNOB	1
61	A04165	PAD-RUBBER CUSHIONING (SHORT)	3
62	A04170	PLUG-PAD	1
63	A04208	LOCATING PIN	3
64	A04209	GASKET-CASE	1
78	A04249	SOCKET HEAD CAP SCREW	3
79	A04250	WIRE GROUND	1
81	A04252	CRANK CASE-LEFT	1
84	A04219	SNAP RING	1
85	A04220	OIL SEAL	1
86	A04221	OIL SEAL PLATE	1
87	A04222	SOCKET HEAD CAP SCREW M4X6	2
88	A03926	NUT M8	1
89	A04223	FLYWHEEL	1
90	A04216	SOCKET HEAD CAP SCREW M5X30	3
91	A04215	SOCKET HEAD CAP SCREW M5X25	1
92	A04254	OIL CAP	2
93	A04255	OIL CAP GASKET	1




POS.	CODE	DESCRIPTION	QTY
94	A04256	WIRE-SWITCH	1
95	A03929	SOKET HEAD CAP SCREW M5X20	2
96	A04268	ELECTRONIC IGNITION	1
97	A04258	ELECTRONIC IGNITION CAP	1
98	A04212	HOSE OIL JOINT	1
99	A04211	HOSE OIL	1
100	A04210	RING-SNAP	2
101	A04259	HEAT RESISTANT PIPE	1
109	A04261	CRANK CASE-RIGHT	1
110	A04193	VALVE VENT	1
111	A04192	AERATE SPIGOT RING -SNAP	1
112	A04191	AERATE SPIGOT SPONGE	1
113	A03977	SPIKE	1
114	A04262	STUD M8X46	2



POS.	CODE	DESCRIPTION	QTY
23	A04271	CROSS RECESSED PAN HEAD SCREW	1
43	A04244	SCREW M5X14	1
SET 1	A04177	CLUTCH ASSEMBLY	1
48	A04178	WASHER-CLUTCH	1
49	A04179	DRUM-CLUTCH	1
50	A04230	SPROCKET	1
51	A04180	BEARING-NEEDLE CONROD	1
52	A04181	GEAR-WORM	1
53	A04182	SOCKET HEAD CAP SCREW M4X12	3
54	A04183	OIL PUMP COVER PLATE	1
115	A04190	PAD RUGHT	1
116	A04189	PLATE-OIL OUT	1
117	A04263	SOKET HEAD CAP SCREW M4X10	1
118	A04172	OIL FILTER	1
119	A04175	OIL PIPE	1
120	A04174	SPONGE-OIL PUMP	1
121	A04176	OIL PUMP	1
122	A04184	OIL OUTLET-OIL PUMP	1
123	A04264	SCREW M4X14	2
124	A04187	SPRING-DAMPING	1
125	A04186	SPRING-DAMPING SUPPORT	1
126	A04185	CHAIN CATCHER	1




POS.	CODE	DESCRIPTION	QTY
25	A04164	GASKET	1
26	A04163	SUPPORT CARBURETOR	1
27	A04162	HEAT PROTECTION GASKET	1
28	A04161	FLANGE-CARBURETOR	1
29	A04145	FUEL INLET TUBE	1
30	A04160	CARBURETOR	1
31	A04237	ROD-THROTTLE	1
32	A04082	FUEL PIPE SPRING	1
33	A04146	SHOCK-REDUCING RUBBER	1
34	A04147	SOKET HEAD CAP SCREW M5X50	2
35	A04238	INLET ELBOW	1
36	A04239	AIR FILTER	1
37	A04240	AIR FILTER COVER	1
38	A04241	IDLING ADJUST GUIDE BUSH	1
39	A04242	KNOB-AIR FILTER	1
40	A04014	GASKET-KNOB	1
41	A04158	SNAP-TOP COVER	2
42	A04243	AIR FILTER COVER	1
43	A04244	SCREW M5X14	5
44	A04245	COVER- TOP	1
78	A04249	SOKET HEAD CAP SCREW	2




POS.	CODE	DESCRIPTION	QTY
SET 2	A12567	BRAKE COVER ASSEMBLY	1
115	A04190	PAD RUGHT	1
127	A04406	BRAKE COVER	1
128	A04407	DIAMOND DAMPER	1
129	A04408	NUT M8	2
130	A04409	FLAT GASKET	2
131	A04410	PLATE-BRAKE	1
132	A04411	SPRING Ø4	2
133	A04412	PIN-LEVER	1
134	A04413	SPRING Ø3	1
135	A04414	LEVER-CHAIN BRAKE	1
136	A04415	PIN	1
137	A04416	VICE-SPRING-ACTUATION	1
138	A04417	MAIN SPRING-ACTUATION	1
139	A04418	PLATE-BRAKE	1
140	A04419	PIN 3X9	2
141	A04420	PUSHER-SPRING (BRAKE) B	1
142	A04421	PUSHER-SPRING (BRAKE) A	1
143+144	A04422	TOOTH-CHAINADJUSTING SET	1
145	A04424	SPROCKET-CHAIN ADJUSTING	1
146	A04425	COVER -BRAKE SPRING	1
147	A04426	CROSS RECESSED PAN HEAD SCREW ST4.2X9.5	5
148	A04427	RUBBER RING	1
149	A04428	SPRING-LEVERAGE	1
150	A04429	HOLLOW PIN	1
151	A04430	PLATE-BAR	1
152	A04431	PIN 3X8	1
153	A04432	BAND-BRAKE	1
154	A04433	STRAP-RUBBER	1


**SET 3:
STARTER
ASSEMBLY**



POS.	CODE	DESCRIPTION	QTY
SET 3	A12566	STARTER ASSEMBLY	1
43	A04244	SCREW M5X14	4
155	A04434	SCREW	1
156	A04435	FLAT GASKET-PULLEY	1
157	A04436	PULLEY COVER	1
158	A04437	SPRING-STARTER	1
159	A04438	PULLEY-STARTER	1
160	A04439	RESET SPRING-STARTER	1
162	A04440	STARTER COVER	1
163	A04441	COVER-ROPE	1
164	A04442	HANDLE-ATARTER	1
165	A04443	ROPE-STARTER	1



POS.	CODE	DESCRIPTION	QTY
1	A04231	FUEL TANK	1
2	A04272	SCREW ST4.8X19	1
3	A04137	LEVER-SAFETY TRIGGER	1
4	A04232	COVER-REAR HANDLE	1
5	A03965	OIL PRIMER	1
6	A04138	TRIGGER SAFETY	1
7	A04000	SPRING-TRIGGER	1
8	A04049	PIN-TRIGGER 6X28	1
9	A04139	PAD-RUBBER CUSHIONING (LONG)	2
10	A04233	PLUG-PAD (BIG)	2
11	A04133	SCREW L30	2
12	A03979	BALANCER SUPPORT	1
13	A03980	BALANCER SUPPORT	1
14	A04142	OIL RETURN PIPE	1
15	A04234	FUEL PIPE	1
16	A04235	FUEL FILTER SPRING	1
17	A04143	FUEL FILTER	1
18	A04135	SHOCK-REDUCING RUBBER (DUPLES NAIL)	1
19	A04131	FUEL CAP	1
20	A04236	O SHAPE GASKET	1
21	A04129	LINKER	1
22	A03997	SWITCH	1
82	A04253	HANDLE	1
83	A04271	SCREW ST4.8X16	4



POS.	CODE	DESCRIPTION	QTY
60	*	CHAIN 0.325"-1,5mm-78	1
80	A04251	GUIDE BAR COVER	1
161	*	GUIDE BAR 50cm- 0.325" - 1.5mm	1
166	A04024	ALLEN	1
167	A04025	PLUG WRENCH	1
168	A04026	SCREDRIVER FOR CARBURETOR ADJUSTMENT	1

* MORE DETAILS TO OUR CATALOGUE