




POS.	CODE	DESCRIPTION	QTY
1	A02209	RIGHT BRACKET	1
2	A02210	LEFT BRACKET	1
3	A02211	SCREW	6
4	A02212	PLATE	2
5	A02213	REAR DOOR	1
6	A02214	REAR CONVEYOR	1
7	A02215	SCREW	2
8	A02216	BELT PROTECTION	1
9	A02217	SCREW	2
10	45712	MULCHING DEFLECTOR	1
11	A02218	DECK	1
12	A02219	CAP	1
13	A02220	O-RING	1
14	A02221	SCREW	1
15	45904	WASHING CONNECTION	1




POS.	CODE	DESCRIPTION	QTY
1	A02203	AXLE, FRONT WHEELS	1
2	A02222	SUPPORT	2
3	A02223	SCREW	4
4	A02224	ROD, HEIGHT ADJUSTMENT	2
5	A02225	PIN	2
6	A02226	PLATE	2
7	A02227	SPRING	1
8	A02204	REAR WHEEL AXLE	1
9	A02228	WHEELS REAR ADJ. LEVER	1
10	A02229	PIN	1
11	A02230	SPRING	1
12	A02231	NUT	1
13	A02232	SUPPORT	2




POS.	CODE	DESCRIPTION	QTY
1	A02245	SCREW	2
2	A02246	MASK	1
3	A02247	INSERT	1
4	A02248	HANDLE	1




POS.	CODE	DESCRIPTION	QTY
1	A02249	HANDLE, LOWER PART	1
2	A02250	NUT	2
3	A02251	WASHER	2
4	A02252	ELASTIC WASHER	2
5	A02253	SCREW	2
6	A02254	OUTFIT, SCREWS	1



POS.	CODE	DESCRIPTION	QTY
1	A02255	HANDLE, UPPER PART	1
2	A02256	GUIDE SPRING	1
3	A02257	WASHER	1
4	A02258	NUT	1
5	A02259	CONDUIT CLIP	1
6	A02260	LEVER, ENGINE BRAKE	1
7	A02195	CABLE, THREAD ENGINE BRAKE	1
8	A02261	SCREW	1
9	A02262	NUT	1
12	A02265	CABLE HOLDER	1





POS.	CODE	DESCRIPTION	QTY
1	A02266	BEARING	4
2	A02198	WHEEL Ø 200	2
3	A02267	HUB CAP	2
4	A02271	WHEEL Ø 280	2
5	A02270	HUB CAP	2
6	A02269	SCREW	6
7	A02202	WHEELS CROWN	2
8	A02272	SPACER	2




POS.	CODE	DESCRIPTION	QTY
1	A02273	SCREW	3
2	A02196	HUB, CRANKSHAFT	1
3	45899	LEFT MULCHING, BLADE	1
4	A02274	ELASTIC DISC	1
5	A02275	WASHER	1
6	A02276	SCREW	1
7	A02277	KEY	1

POS.	CODE	DESCRIPTION	QTY
1	A02278	REAR DOOR	1
2	A02279	GRASS-BOX, UPPER PART	1
3	A02201	FABRIC BOX	1
4	A02280	WASHER	2
5	A02281	SPRING	2
6	A02282	LOWER STIFFENING	1
7	A02283	PIN	1
8	A02284	STONE GUARD SUPPORT	1
9	A02285	SCREW	1
10	A02286	STONE GUARD	1
11	A02287	SCREW	2
12	A02288	OUTFIT, PLASTIC PIN	1
13	A02289	OUTFIT, SCREWS	1







POS.	CODE	DESCRIPTION	QTY
2	A02290	NUT	3
3	A02291	STARTER ASSEMBLY	1
4	A02292	STARTER HANDLE	1
5	A02293	STARTING ROPE	1
6	A02294	STARTER SPRING	1
7	A02295	STARTER PULLEY	1
8	A02296	SPRING	2
9	A02297	RATCHET, STARTER	2
10	A02298	SPRING	1
11	A02299	COVER	1
13	A02300	STUD	1
14	A02133	AIR GUIDE	1
15	A02134	PIN	2
16	A02135	PIN	1
17	A02136	SCREW	1
18	A02137	ELETTRONIC COIL	1
20	A02138	SPARK PLUG	1
21	A02139	SCREW	2
22	A02140	CHOKE CONTROL	1
23	A02141	CONTROL ROD	1
24	A02142	RETAINER	1
25	A02143	CARBURETTOR	1
26	A02145	STUD BOLT	2
27	A02146	GASKET	1
28	A02147	INSULATOR, CARBURETTOR	1
29	A02148	GASKET	1
30	A02149	GASKET	1
31	A02150	AIR CLEANER ASSEMBLY	1





POS.	CODE	DESCRIPTION	QTY
32	A02151	AIR FILTER	1
33	A02152	AIR FILTER	1
34	A02153	AIR CLEANER COVER	1
35	A02154	NUT	2
36	A02155	FUEL PIPE	1
37	A02156	PIPE CLIP	2
38	A02157	FUEL FILTER	1
39	A02158	TANK	1
40	A03300	FUEL TANK CAP ASS.	1
41	A02160	SCREW	2
42	A02161	BREATHER FUEL PIPE	1
43	A02162	ARM GOVERNOR	1
44	A02163	PLATE	1
45	A02164	SCREW	1
46	A02165	SPRING	1
47	A02166	SCREW	1
48	A02167	NUT	1
49	A02199	GOVERNOR LINK	1
50	A02168	GASKET, MUFFLER	1
51	A02169	MUFFLER	1
52	A02170	SCREW	2
53	A02171	MUFFLER GUARD	1
54	A02172	BOLT	3



POS.	CODE	DESCRIPTION	QTY
1	A02173	NUT	1
2	A02174	FLYWHEEL ASSEMBLY	1
3	A02175	BOLT	1
4	A02176	SCREW	1
5	A02177	FLYWHEEL BRAKE/STOP SWITCH ASS.	1
6	A02178	SPRING	1
7	A02179	OIL SEAL	1
8	A02180	CYLINDER ASSY	1
9	A02181	SCREW	2
10	A02182	COVER	1
11	A02183	GASKET, BREATH GROOVE	1
12	A02184	VALVE	1
13	A02185	CRANKSHAFT	1
14	A02187	WOODRUFF KEY	1
15	A02188	WASHER	1
16	A02189	CAMSHAFT ASSY	1
18	A02190	SCREW	1
19	A02191	SPEED GOVERNOR ASSY	1
20	A02192	SHAFT, GOVERNOR ARM	1
21	A02193	WASHER	1
22	A02194	OIL SEAL	1
23	A02107	COTTER PIN	1
24	A02108	OIL SEAL	1
25	A02109	CRANKCASE COVER	1
26	A02110	TANK CAP	1
27	A02111	SCREW	10
28	A02112	BOLT	4



POS.	CODE	DESCRIPTION	QTY
29	A02113	COVER COMP. HEAD	1
30	A02114	PACKING HEAD COVER	1
31	A02115	VALVE ARM SET	2
32	A02116	PLATE	1
33	A02117	RETAINER	2
34	A02118	SPRING	2
35	A02119	VALVE ASS. INTAKE + EXHAUST	1
36	A02120	VALVE LIFTER ASSY	2
37	A02121	PUSH ROD	2
38	A02122	PISTON	1
39	A02123	PISTON, RING SET	1
40	A02124	PISTON PIN	1
41	A02125	WASHER, PISTON PIN	2
42	A02126	CONNECTING ROD ASSEMBLY	1
43	A02128	GRUB SCREW	2
45	A02200	ENGINE GASKET SET	1



POS.	CODE	DESCRIPTION	QTY
1	A02130	COVER	1
2	A02131	HOOD	1
3	A02132	COVER	1