



POS.	CODE	DESCRIPTION	QTY
1	A07462	BOLT	6
2	A07557	SPRING WASHER	6
3	A07464	CYLINDER HEAD	1
4	A07465	GASKET	1
5	A07466	VALVE SEAT	1
6	A07467	ALUMINUM GASKET	1
7	A07468	VALVE PLATE	4
8	A07469	VALVE SEAT	1
9	A07470	GASKET	1
10	A07471	CYLINDER	1
11	A07472	GASKET	1
12	A07473	CRANK CASE	1
13	A07474	BOLT	2
14	A07475	AIR CLEANER	1
15	A07476	BOLT	4
16	A07477	SPRING WASHER	4
17	A07478	CRANK CASE COVER	1
18	A07479	GASKET	2
19	A07480	BEARING	2
20	A07481	CRANK SHAFT	1
21	A07482	OIL FULL	1
22+23	A07483	OIL SIGHT GLASS	1
24	A07485	BOLT	1
25	A07486	GASKET	1
26	A07487	CRANKCASE COVER	1
27	A07488	BOLT	12

POS.	CODE	DESCRIPTION	QTY
28	A07489	NUT	4
29	A07490	SPRING WASHER	4
30	A07491	FLAT WASHER	8
31	A07492	BOLT	4
32	A07493	CONNECT	1
33	A07494	PISTON RING	2
34	A07495	PISTON	2
35	A07496	SNAP RING	4
36	A07497	WRIST PIN	2
37	A07498	CONNECTING ROD	2
38	A07499	SPRING WASHER	6
39	A07500	BOLT	6
40	A07501	SHAFT SEAL	1
41	A07502	CRANKCASE COVER	1
42	A07503	SPRING WASHER	4
43	A07504	BOLT	4
44	A07505	PULLEY	1
45	A07506	BOLT	1
46	A07507	FLAT WASHER	1
47	A07508	BOLT	4
48	A07509	FLAT WASHER	8
49	A07510	SPRING WASHER	4
50	A07511	NUT	4
51	A07512	MOTOR	1
52	A07513	PULLEY	1
53	A07514	KEY	1

POS.	CODE	DESCRIPTION	QTY
54	A07515	NUT	1
55	A07516	SPRING WASHER	1
56	A07517	CONNECTING PLATE	1
57	A07518	FLAT WASHER	1
58	A07519	BOLT	1
59	A07520	SPRING WASHER	1
60	A07521	BOLT	1
61.1	A07522	FENDER	1
61.2	A07522	FENDER	1
62	A07523	NUT	2
63	A07524	SPRING WASHER	2
64	A07525	FLAT WASHER	4
65	A07526	BOLT	2
66	A07527	BELT	1
67	A07528	NUT	2
68	A07529	SPRING WASHER	2
69	A07531	WHEEL	2
70	A07532	PIN	2
71	A07533	AIR COCK	1
72	A07534	REGULATOR	1
73	A07535	CONNECT	1
74	A07536	PRESSURE SWITCH	1
75	A07537	CABLE 3X1.5	1
76	A07538	SAFETY VALVE	1
77	A07539	CONNECT	1
78	A07540	PRESSURE GAUGE	1

POS.	CODE	DESCRIPTION	QTY
79	A07541	PRESSURE GAUGE	1
80	A07542	BOLT	4
81	A07543	FLAT WASHER	8
82	A07544	SPRING WASHER	4
83	A07545	NUT	4
84	A07546	DRAIN COCK	1
85	A07530	TANK 150L	1
86	A07548	WHEEL	1
87	A07549	SPRING WASHER	4
88	A07550	BOLT	4
89	A07551	HANDLE	1
90	A07552	PLUG	2
91	A07553	CONNECT	1
92	A07554	CHECK VALVE	1
93	A07555	EXHAUST PIPE	1
94	A07556	UNLOADING ASSEMBLY	1