



| POS. | CODE | DESCRIPTION | QTY |
|----------------------|--------|--------------------------------------|-----|
| 1 | A00509 | SCREW | 10 |
| 2 | A00510 | NAMEPLATE & LOGO STICKER | 1 |
| SET 1 (3+15) | A00511 | LEFT & RIGHT HOUSING | 1 |
| 4 | A00512 | SWITCH | 1 |
| 5 | A00513 | SWITCH COVER | 1 |
| 6 | A00514 | DUST PORT | 1 |
| 7 | A00515 | BEARING 606 | 1 |
| 8 | A00516 | STATOR | 1 |
| 9 | A00411 | POWER CORD | 1 |
| 10 | A00517 | INSERT BOARD | 1 |
| 11 | A00518 | INSERT BOARD COVER | 1 |
| 12 | A00519 | INSERT SPRING | 1 |
| 13 | A00379 | POWER CORD GUARD | 1 |
| 14 | A00386 | POWER CORD PRESSURE | 1 |
| 16 | A00521 | BRUSH SUPPORT | 2 |
| 17 | A00522 | BRUSH SPRING | 2 |
| 18 | A00523 | CARBON BRUSH | 2 |
| SET 2 (16-18) | A12211 | CARBON BRUSH (ASSEMBLY WITH SUPPORT) | 2 |
| 19 | A00524 | CAPACITANCE | 1 |
| 20 | A00525 | INSERT SPRING | 2 |
| 21 | A00526 | INSERT SPRING | 2 |
| 22 | A00527 | INNER DUST PIPE | 1 |
| 23 | A00528 | REAR SUPPORTOR | 1 |
| 24 | A00529 | UPSIDE BASE PLATE | 1 |

| POS. | CODE | DESCRIPTION | QTY |
|----------------------|--------|---------------------|-----|
| SET 3 (25+26) | A13107 | BASE PLATE ASSEMBLY | 1 |
| 27 | A00532 | SCREW | 5 |
| 28 | A00533 | ROTOR | 1 |
| 29 | A00534 | BEARING 608 | 1 |
| 30 | A00535 | ECCENTRIC WHEEL | 1 |
| 31 | A00437 | BEARING 628 | 1 |
| 32 | A00536 | FRONT SUPPORT | 1 |
| 33 | A00537 | PIN | 1 |
| 34 | A00538 | SCREW | 4 |