


POS.	CODE	DESCRIPTION	QTY
1	42408	BATTERY 40V, 5Ah	1
2	A03565	SCREW	22
3	A03566	HANDLE	1
4	A03567	PCB	1
5	A03568	TRIGGER	1
6	A03569	PAD	2
7	A03570	SWITCH SPRING	1
8	A03571	HANDLE	1
9	A03572	BUTTON	1
10	A03573	BUTTON SPRING	1
11	A03574	DOUBLE TORSION SPRING	1
12	A03575	SPRING POSITIONING SHAFT	1
13	A03576	SPRING	1
14	A03577	LOCKING LEVER	1
15	A03578	CABLE CLAMP	2
16	A03579	TUBE ASSEMBLY	1
17	A03580	TWO-CORE SPRING CONNECTING WIRE	1
18	A03581	THERMAL CASING	0,15m
19	A03582	HOUSING	1
20	A03583	HOUSING	1
21	A03584	WIRE RACK	1
22	A03585	MOTOR ASSEMBLY	1
23	A03586	FIXED PLATE	1
24	A03587	SCREW	2
25	A03588	OUTPUT SHAFT SLEEVE	1
26	A03589	HANDLE ASSEMBLY	1
27	A03590	PROTECTIVE COVER ASSEMBLY	1



POS.	CODE	DESCRIPTION	QTY
28	A03591	ANTI-LOST SCREW	1
29	A03592	GRASS HEAD ASSEMBLY	1
30	42409	BATTERY CHARGER 40V	1
31	A03593	CABLE ASSEMBLY	1
32	A03594	COPPER TAPE	32
33	A03595	MAGNETIC RING	2
34	A03596	MAGNETIC RING	1
35	A03597	BUTTER	1
36	A03598	SWITCH PAD	2