



POS.	CODE	DESCRIPTION	QTY
1	42408	BATTERY 40V, 5Ah	1
2	A03618	BATTERY PACK BUTTON	1
3	A03619	BUTTON SPRING	1
4	A03620	PCB	1
5	A03621	DOUBLE TORSION SPRING	1
6	A03622	SPRING POSITIONING SHAFT	1
7	A03623	LEFT HANDLE	1
8	A03624	LOCKING LEVER	1
9	A03625	SPRING	1
10	A03626	SWITCH TRIGGER	1
11	A03627	SWITCH SPRING	1
12	A03628	SCREW	22
13	A03629	RIGHT HANDLE	1
14	A03630	HEAT SHRINKABLE TUBE	4mm
15	A05158	COPPER TAPE	16mm
16	A03632	SELF-TAPPING SCREWS	6
17	A03633	CABLE CLAMP	2
18	A03634	SPRING CABLE	1
19	A03635	STRAP RING ASSEMBLY	1
20	A03636	TUBE ASSEMBLY	1
21	A03637	BUTTON	1
22	A03638	LEFT HANDLE CONNECTION HANDLE	1
23	A03639	RIGHT HANDLE CONNECTION HANDLE	1
24	A03640	SCREWS	2
25	A03641	FOLLOWER BUTTON	1
26	A03642	STEERING BUTTON SPRING	1

POS.	CODE	DESCRIPTION	QTY
27	A03643	LEFT HOUSING	1
28	A03644	PCB	1
29	A03645	FEMALE TERMINAL	2
30	A03646	HEAT SHRINKABLE TUBE	6mm
31	A03647	OUTLET NOZZLE ASSEMBLY	1
32	A03648	TRANSPARENT OIL PIPE (OIL OUT)	6.5mm
33	A03649	OIL PUMP ASSEMBLY	1
34	A03650	SCREWS	2
35	A03651	HEAT SHRINKABLE TUBE	9mm
36	A03652	SCREWS	4
37	A03653	MOTOR COVER	1
38	A03654	MOTOR COMPONENTS	1
39	A03655	RIGHT CASING INSERT SEALING PLUG	2
40	A03656	RIGHT HOUSING	1
41	A03657	SEALING RING	1
42	A03658	SCREWS	4
43	A03659	WOOL FELT	1
44	A03660	TENSION SPRING	1
45	A03661	SPROCKET	1
46	A03662	RETAINING RING	1
47	A03663	FUEL TANK COVER ASSEMBLY	1
48	A03664	FUEL TANK COMPONENTS	1
49	A03665	END CAP ASSEMBLY	1
50	A03666	PUSH BOARD	1
51	A03667	PUSH PLATE SEALING RING	1
52	A03668	CHAIN BAR 25cm-3.8"-1.3	1

POS.	CODE	DESCRIPTION	QTY
53	A03669	CROSS RECESSED PAN HEAD SCREWS	1
54	A03670	CHAIN SAW 3.8"-1.3-40	1
55	A03672	KNIFE SET	1
56	42409	BATTERY CHARGER 40V	1
57	A03673	SWITCH PAD	2