



POS.	CODE	DESCRIPTION	QTY
1	A01123	BRAKE LEVER CAP	1
2	A01124	BRAKE LEVER	1
3	A01125	MAIN BUTTON MOVE LEVEL	1
4	A01126	BRAKE LEVER SPRING	1
5	A01127	OPEN MOUTH RING	1
6	A01128	MOTOR COVER	1
7	A01129	CARBON BRUSH	2
8	A01130	TAPING SCREW ST3X8	2
9	A01131	SELF-TAPING SCREW M4X16	4
10	A01132	STATOR	1
11	A01133	TAPING SCREW ST4X45	2
12	39618	BALL BARING 607-2RS	1
13	A01134	ROTOR	1
14	39619	BALL BEARING 608-2RS	1
15	A01135	WINDSHIELD	1
16	A01136	SUPPORT CENTER	1
17	A01137	FLAT WASHER	4
18	A01138	SPRING WASHER	2
19	A01139	TAPING SCREW ST5X18	2
20	A01140	INSERT SPRING	2
21	A01141	MICRSOFTSWITCH	1
22	A01142	CAPACITANCE	1
23	A01143	COMMON MODE CHOKE	1
24	A01144	WIRING TERMINAL	1
25	A01145	CABLE SLEEVE	1
26	A01146	POWER LINE	1
27	A01002	SLIM WASHER	4
28	A01147	GEAR ASSEMBLY	1

POS.	CODE	DESCRIPTION	QTY
29	A00792	FLANGE NUT M6 (LEFT)	1
30	A00847	ECCENTRIC BLOCK COVER	1
31	A00892	HEXAGON SCREW M5X8	2
32	A01148	SELF LOCKING NUT M5	2
33	A01149	HEXAGON NUT M5	2
34	A01150	BLADE WASHER	2
35	A01151	LINER RING	2
36	A01152	BLADE ASSEMBLY	1
37	A01153	SELF-TAPING SCREW M5X12	4
38	A01154	BASE BOARD	1
39	A01155	SQUARE NUT M5	4
40	A01156	RIGHT HOUSE	1
41	A01157	SELF-TAPING SCREW ST4X25	4
42	A01158	RIGHT TOP COVER	1
43	A01159	BRAKE LEVER SPRING	1
44	A01160	DEPUTY BUTTON MOVE LEVEL	1
45	A01161	WIRE MOVE LEVEL	1
46	A01162	SOFT SHAFT SPRING	1
47	A01163	SOFT SHAFT	1
48	A01164	FIXED SEAT	1
49	A01165	GRADUATED RING	1
50	A01166	LEFT HOUSE	1
51	A01167	LEFT TOP COVER	1
52	A01168	ROTARY PUSH BUTTON	1
53	A01169	LEFT HANDLE	1
54	A01170	SELF-TAPING SCREW ST4X14	15
55	A01171	PRESS BOARD	1
56	A01172	MAIN BUTTON SPRING	1

POS.	CODE	DESCRIPTION	QTY
57	A01173	MAIN HANDLE BUTTON	1
SET 1 (58-61)	A01174	DEPUTY HANDLE ASSEMBLY	1
62	A01175	RIGHT HANDLE	1
63	A01176	SELF-TAPING SCREW ST4X16	6