



POS.	CODE	DESCRIPTION	QTY
1	A01322	POWER WIRE	1
2	A01323	FLOATER SWITCH	1
3	A01324	SCREW	4
5	A01325	REAR PUMP HOUSING	1
5.1	A01326	HANDLE COVER	1
6.1	A01327	CABLE SHEATH	1
6.2	A01354	CABLE SHEATH	1
7.1	A01329	CABLE BUCKLE	1
7.2	A01330	CABLE BUCKLE	1
8	A01351	CAPACITOR 12µF	1
9	A01332	CABLE BLOCK	1
10	A01333	SELF-TAPPING SCREW	3
<b>11-21 (SET 1)</b>	A01352	STEEL REAR COVER	1
22	A01335	O - RING	1
23	A01336	ADJUSTING GASKET	1
24	A01355	IMPELLER	1
25	A01338	NUT	1
<b>26</b>	A01356	MAIN PUMP HOUSING	1
27	A01340	O - RING	1
28	A01357	PUMP BASE	1
29	A01342	SELF-TAPPING SCREW	3
30	A01358	BASEPLATE	1
31	A01359	SCREW	3
32	A01343	O - RING	2
33	A01344	ELBOW	1

POS.	CODE	DESCRIPTION	QTY
34	A01345	OUTPUT CONNECTOR	1
36	A01346	EARTH COVER	1
37.1	A01420	NYLON SAFETY PRESSING CAP	2
37.2	A01347	NYLON SAFETY PRESSING CAP	3
39	A01348	RIBBON	1
40	A01349	MECHANICAL SEAL	1
41	A01350	CHECK RING	1