



POS.	CODE	DESCRIPTION	QTY
1	A01323	FLOAT SWITCH	1
2	A01322	POWER CABLE	1
3	A01359	SCREW	2
4	A01393	HANDLE	1
5	A01394	SELF-TAPPING SCREW	6
5.1	A01395	GASKET	12
6	A01396	REAR PUMP HOUSING	1
7	A01397	O-RING	2
8	A01383	SELF-TAPPING SCREW	1
9	A01382	O-RING	1
10	A01398	REAR COVER	1
11	A01399	CAPACITOR 20 µF	1
12	A01332	CABLE BLOCK	1
13	A01333	SELF-TAPPING SCREW	3
14	A01327	CABLE SHEATH	2
15	A01330	CABLE BUCKLE	2
16-35 (SET 1)	A01401	MOTOR ASSEMBLY	1
36	A01335	O-RING	1
37	A01402	ALUMINUM PRESSING RING	1
38	A01403	SELF TAPPING SCREW	6
39	A01404	O-RING	1
40	A01405	MAIN PUMP HOUSING	1
41	A01406	O-RING	1
42	A01407	MECHANICAL SEAL	1
43	A01408	BUSHING	1

POS.	CODE	DESCRIPTION	QTY
44	A01409	DIFFUSER PLATE	4
45	A01410	O-RING	4
46	A01411	IMPELLER	4
47	A01412	PLASTIC GASKET	4
48	A01413	INNER BASE	1
49	A01414	SPRING WASHER	1
50	A01415	HEXAGON BOLT	1
51	A01416	GASKET	4
52	A01417	SCREW	4
53	A01418	STAINLESS STEEL SHIELD	1
54	A01419	PUMP BASE	1
55	A01400	SELF TAPPING SCREW	3
56	A01346	EARTH COVER	1
57	A01420	NYLON SAFTY PRESSING CAP	2
58	A01347	NYLON SAFTY PRESSING CAP	3
60	A01348	RIBBON	1
61	A01421	SELF TAPPING SCREW	2