




POS.	CODE	DESCRIPTION	QTY
3	A04040	SCREW ST4.8*16	1
76	A04068	WASHER M5	2
77	A04069	HEX. NUT M5	2
78	A04070	MUFFLER	1
79	A04071	MUFFLER GASKET	1
80	A04072	SCREW M5X60	2
81	A04073	CYLINDER 40,5mm	1
82	A03929	INNER HEXAGON SCREW M5X20	4
83	A03934	SPARK PLUG	1
84	A04074	AIR INTAKE GASKET	1
85	A04075	AIR INTAKE	1
86	A04076	CARBURETOR GASKET	1
87	A04077	CARBURETOR	1
88	A04078	INLET ELBOW	1
89	A04079	CARBURETOR SCREW PIPE BRANCH	2
90	A04080	INNER PLUM-SHAPED SCREW M4X70	2
91	A04081	FUEL PRIMER INLET PIPE	1
92	A04082	FUEL-OUT SPRING	1
111	A04097	BEARDING NEEDLE	1
112	A04351	PISTON PIN	1
113	A04098	CYLINDER GASKET	1
114	A04352	PISTON RING	1
115	A04353	PISTON 40,5mm	1
116	A04354	PISTON RING-SNAP	2
117	A04099	BEARING RETAINER	2
118	A04100	CRANK SHAFT ASSEMBLY	1
119	A03922	KEY	1



POS.	CODE	DESCRIPTION	QTY
2	A03943	SCREW M5X14	1
93	A04083	CLUTCH DRUM	1
94	A03962	NEEDLE BEARING	1
95	A04084	WORM GEAR	1
96	A03958	SCREW M4X14	4
97	A04085	COVER-OIL PUMP	1
98	A04086	SWITCH LINE	1
99	A04087	THERMAL SLEEVE	1
100	A04088	OUTLET PIPE-OIL	1
101	A04089	OIL VALVE VENT	1
102	A03956	WORM GEAR WASHER	1
103	A04090	SCREW M4X10	1
104	A04091	OIL OUTLET PLATE	1
105	A04092	SCREW M5X30	4
106	A04093	STUD DOUBLE END BOLT (LONGER)	1
107	A04094	STUD DOUBLE END BOLT (SHORTER)	1
108	A03977	SPIKE	1
109	A04095	PIN	3
110	A04096	BEARING 6201	2
120	A04101	SWITCH OFF LINE	1
121	A04102	IGNITION COIL	1
122	A04103	SCREW M4X14	2
123	A03926	FLANGE NUT M8	1
124	A04104	FLYWHEEL	1
125	A04105	OIL SEAL 12X22X7	1
126	A04106	LEFT CRANK CASE	1
127	A04107	CRANK CASE GASKET	1




POS.	CODE	DESCRIPTION	QTY
128	A04108	RETAINER RING	1
129	A04109	RIGHT CRAKE CASE	1
130	A04110	CHAIN CATCHER	1
131	A04111	OIL SEAL 12X32X5X5	1
132	A04112	SCREW M5X32	1
133	A04113	OIL INLET PIPE	1
134	A03957	OIL PUMP	1
135	A04114	CLUTCH WASHER	1
SET 1	A04177	CLUTCH	1




POS.	CODE	DESCRIPTION	QTY
1	A04039	SPRING -CRANK CASE	1
2	A03943	SCREW M5X14	5
3	A04040	SCREW ST4.8X16	7
4	A04129	LINKER	2
5	A04041	FUEL CAP GASKET	1
6	A04042	FUEL CAP	1
7	A04043	OIL CAP	1
8	A04044	OIL CAP GASKET	1
9	A04045	FUEL TANK	1
10	A04046	OIL FILTER	1
11	A04047	OIL FILTER TIP	1
12	A04048	PIPE - JOINT	1
13	A03997	SWITCH ON - OFF	1
14	A03965	FUEL PRIMER	1
15	A04049	PIN	1
16	A04050	TRIGGER	1
17	A04051	LEVER-SAFETY TRIGGER	1
18	A04000	SPING -TRIGGER	1
19	A04052	ROD THROTTLE	1
20	A04053	REAR HADNLE COVER	1
21	A04054	VENTILATE FUEL PIPE	1
22	A03975	HEXAGONAL SCREW	1
23	A04055	SUPPORT - HOSE FUEL	1
24	A03981	FUEL FILTER	1
25	A03980	VENTILATION VALVE	1
26	A03979	SUPPORT - VENTILATION	1




**SET 2:  
BRAKE COVER  
ASSEMBLY**



POS.	CODE	DESCRIPTION	QTY
<b>SET 2</b>	A12561	BRAKE COVER ASSEMBLY	1
41	A04326	BRAKE COVER	1
<b>SET 3 (42+45)</b>	A04327	SCREW CHAIN ADJUSTING SET	1
43	A04328	SPROCKET-CHAIN ADJUSTING	1
44	A04329	PLATE-BAR	1
46	A04331	SCREW ST4.2x9.5	4
47	A04332	SPRING COVER PLATE	1
48	A04333	BRAKE SPRING	1
49	A04334	BAND BRAKE	1
50	A04335	ROUND PIN	2
51	A04336	ROUND PIN	1
52	A04337	PUSHER-SPRING BRAKE	1
53	A04338	PUSHER-SPRING BRAKE	1
54	A04339	BRAKE CONTROL POLE	1
55	A04340	PIN-LEVERAGE	1
56	A04341	PIN	1
57	A04342	INNER PLUM-SHAPED SCREW M5X40	1
58	A04022	NUT M8	2
59	A04343	LEVERAGE-BRAKE	1
60	A04344	LEVERAGE-BRAKE SPRING	1
61	A04345	PRESSURE SPRING SEAT	2
62	A04346	COMPRESS SPRING-LEVERAGE	1
63	A04347	LEVERAGE	1
64	A04348	TORSIONAL BRAKE SPRING	1
65	A04349	WASHER	1
66	A04350	SCREW	1




POS.	CODE	DESCRIPTION	QTY
<b>SET 4</b>	A12560	STARTER ASSEMBLY	1
3	A04040	INNER PLUM - BLOSSOM SCREW ST4.8X16	1
27	A04056	BAFFLE-FAN	1
28	A04315	FLAT GASKET-PULLEY	1
29	A04316	PULLRY-STARTER COVER	1
30	A04317	SPRING-STARTER	1
31	A04318	PULLEY-STARTER	1
<b>SET 5 (32+33)</b>	A04320	RESET SPRING-STARTER ASSEMBLY	1
34	A04321	COVER-ROPE	1
35	A04322	STARTER HANDLE	1
36	A04323	STARTER ROPE	1
37	A04324	STARTER COVER	1
38	A04325	INNER PLUM-BLOSSOM SCREW ST4.8x19	4



POS.	CODE	DESCRIPTION	QTY
3	A04040	SCREW ST4.8X16	2
38	A04325	SCREW ST4.8x19	1
139	A04115	TOP COVER	1
140	A04116	TRANSFER SLAB	1
141	A04117	CHOKE KNOB PROTECTING BUSH	1
142	A04118	CHOKE KNOB	1
143	A04119	AIR FILTER WASHER	1
144	A04120	AIR FILTER	1
145	A04121	AIR FILTER SCREW	1
146	A04122	AIR FILTER COVER	1
147	A04123	SNAP JOINT	2





POS.	CODE	DESCRIPTION	QTY
148	*	BAR 40cm - 3/8" - 1.3mm	1
149	A04026	SCREW DRIVER	1
150	A04025	SPARK PLUG WRENCH	1
151	A04125	GUIDE BAR COVER	1
152	*	CHAIN 3/8"-1,3mm - 57	1

\* MORE DETAILS TO OUR CATALOGUE