



POS.	CODE	DESCRIPTION	QTY
1	A06830	SCREW	1
2		SANDING PAPER	1
3	46749	SANDING PAD	1
4	A06832	WOOL MAT	1
5	A06833	NYLON BRUSH	1
6	A06834	SIDE COVER	1
7	A06835	REFLECTIVE COVER	1
SET 4 (8-10)	A06836	CONTROLLER ASS.	1
11	A06839	SCREW ST3.9X14	2
12	A06840	SPRING	4
13	A06841	SPINDLE	1
14	A06842	BEARING COVER	1
15	39623	BEARING 6001	1
16	A06843	SCREW M4X12	4
17	A06844	FRONT COVER	1
18	A06845	BEARING 606	2
19	A06846	GEAR SHAFT	1
20	A06847	GEAR	1
21	A06848	GEAR	1
22	A06849	BEARING 6000	1
23	A08273	MOTOR COVER	1
24	A08274	ROTOR	1
25	A08275	STATOR	1
26	A08276	BEAR 698	1
27	A08277	WIND LOOP	1

POS.	CODE	DESCRIPTION	QTY
28	A08278	FANDBLADE	1
29	A08279	SCREW M4X20	1
30	A08280	BACK COVER	1
31	A08281	SCREW M5X60	3
32	A06851	NYLON BRUSH	1
33	A06852	CABLE COVER	2
34	A06853	SCREW ST3.9X8	2
35	A06854	CABLE PLATE	2
36	A00410	THREE-CORE WIRE	1
37	A06855	HOSE	1
38	A06856	HOOP	2
39	A06857	SCREW ST3.9X12	8
40	A06858	BIG GEAR	1
41	A06859	BEARING 607	1
42	A06860	PIN 5X10	2
43	A06861	BUSHING	1
SET 1 (44+48)	A06862	SUPPORT ARM	1
45	A06863	TORSION SPRING	2
46	A06864	SCREW M6X35	1
47	A00412	SCREW ROCK	1
49	A06865	SCREW ST3.9X16	16
50	A06866	ADAPTOR	1
51	A06867	O - RING	2
52	A06868	MAIN TUBE	1

POS.	CODE	DESCRIPTION	QTY
SET 2 (53+59)	A06869	HANDLE (LEFT+RIGHT)	1
54	A06870	ADAPTOR	1
55	A06871	POWER SUPPLY SET	1
56	A06872	EMC	1
57	A06873	CABLE PLATE	1
58.1	A06874	CABLE SEATH	1
58.2	39387	CABLE	1
60	A06875	CONTROL PLATE	1
61	A06876	LIGHT COVER	1
62	A06877	LOCK NUT	1
63	A06878	TUBE	1
SET 3 (64+65)	A06879	HANDLE (LEFT+RIGHT)	1
66	A06880	SCREW ST3.3X10	2
67	A06881	SCREW ST3.9X12	2
68	A08282	HALL PLATE SET	1
69	A08283	RESISTANCE	1
70	A08284	CLIP	1
71	A08285	SPRING PIECE	1
72	47221	VACUUM PIPE 4m	1