



E01




POS.	CODE	DESCRIPTION	QTY
E01-1	A13064	CRANKCASE	1
E01-2	A08287	DRAIN PLUG BOLT	2
E01-3	A08482	FLAT WASHER	2
E01-4	A11172	OIL SEAL	1
E01-5	A11303	SLIDING BEARING	1
E01-6	A09908	GOVERNOR GEAR	1
E01-7	A10669	GOVERNOR ARM	1
E01-8	A08610	FLAT WASHER	1
E01-9	A08951	COTTER PIN	1
E01-10	A11192	ENGINE OIL SENSOR	1
E01-11	A08852	BOLT	2

E02




POS.	CODE	DESCRIPTION	QTY
E02-1	A10784	CRANKCASE COVER	1
E02-2	A08484	DEEP GROOVE BALL BEARING	1
E02-3	A08483	OIL SEAL	1
E02-4	A08939	HEXAGON SOCKET FLANGE FACE BOLT	6
E02-5	A08550	POSITION PIN	2
E02-6	A08468	OIL DIPSTICK SUBASSEMBLY	1
E02-7	A09912	ENGINE OIL PLUG	1

E03




POS.	CODE	DESCRIPTION	QTY
E03-1	A10923	CYLINDER HEAD	1
E03-2	A10779	CYLINDER HEAD COVER	1
E03-3	A10883	CYLINDER HEAD COVER GASKET	1
E03-4	A09937	HEXAGON SOCKET FLANGE FACE BOLT	4
E03-5	A11259	BREATHER TUBE	1
E03-6	A13017	CYLINDER HEAD COVER PIN LIMIT PLATE	1
E03-7	A08293	CYLINDER HEAD BOLT	4
E03-8	A08940	SPARK PLUG	1
E03-9	A08494	HEXAGON SOCKET FLANGE FACE BOLT	2
E03-10	A11207	CYLINDER BODY SHROUD	1
E03-11	A11331	STUD BOLT	2
E03-12	A08556	STUD BOLT	2
E03-13	A10878	CYLINDER HEAD GASKET	1
E03-14	A08866	POSITION PIN	2

E04




POS.	CODE	DESCRIPTION	QTY
E04-1	A10806	CRANKSHAFT ASSEMBLY	1
E04-2	A09641	TIMING DRIVE GEAR	1
E04-3	A11287	FLAT WASHER	1

E05




POS.	CODE	DESCRIPTION	QTY
E05-1	A11120	PISTON RING SET	1
E05-2	A08417	PISTON PIN CLIP	2
E05-3	A11047	PISTON	1
E05-4	A08387	PISTON PIN	1
E05-5	A11145	CONNECTING ROD	1

E06




POS.	CODE	DESCRIPTION	QTY
E06-1	A10732	CAMSHAFT ASSEMBLY	1
E06-2	A11268	VALVES SET	1
E06-3	A08299	SEAL GUIDE	1
E06-4	A08300	VALVE SPRING	2
E06-5	A08301	VALVE SPRING SEAT	2
E06-6	A08302	VALVE LOCK CLAMP	4
E06-7	A09643	VALVE TAPPET	2
E06-8	A11006	VALVE LIFTER	2
E06-9	A09049	ROCKER SHAFT	2
E06-10	A08973	ROCKER VALVE	2

E07




POS.	CODE	DESCRIPTION	QTY
E07-1	A13077	RECOIL STARTER ASSEMBLY	1
E07-2	A08613	HEXAGON SOCKET FLANGE FACE BOLT	3

E08




POS.	CODE	DESCRIPTION	QTY
E08-1	A11203	SHROUD	1
E08-2	A11197	LOWER SHIELD	1
E08-3	A10917	GROUNDING	1
E08-4	A08968	BOLT	4
E08-5	A08924	WIRE CLIP	1
E08-6	A10975	RUBBER JACKET	1
E08-7	A08615	OIL PROTECTOR	1
E08-8	A08852	BOLT	1

E09




POS.	CODE	DESCRIPTION	QTY
E09-1	A13037	CARBURETOR	1
E09-2	A08498	AIR CLEANER SEAL GASKET	1
E09-3	A08469	CARBURETOR SEAL GASKET	1
E09-4	A11058	CARBURETOR INSULATOR PLATE	1
E09-5	A08477	CARBURETOR INSULATOR GASKET	1

E10




POS.	CODE	DESCRIPTION	QTY
E10-1	A08420	FLYWHEEL NUT	1
E10-2	A08618	STARTER PULLEY	1
E10-3	A09674	IMPELLER	1
E10-4	A10843	FLYWHEEL	1
E10-5	A13029	IGNITION COIL	1
E10-6	A08502	BOLT	2

E11




POS.	CODE	DESCRIPTION	QTY
E11-1	A10773	THROTTLE CONTROL	1
E11-2	A11213	GOVERNOR SPRING	1
E11-3	A11150	GOVERNOR ROD	1
E11-4	A11218	THROTTLE VALVE RETURNING SPRING	1
E11-5	A08504	GOVERNOR BRACKET	1
E11-6	A08494	BOLT	2
E11-7	A08505	GOVERNOR SUPPORT BOLT	1
E11-8	A08506	NUT	1

F01




POS.	CODE	DESCRIPTION	QTY
F01-1	A13092	AIR CLEANER	1
F01-2	A08506	NUT	2
F01-4	A11332	AIR CLEANER ELEMENT	1

F02




POS.	CODE	DESCRIPTION	QTY
F02-1	A09055	EXHAUST OUTLET GASKET	1
F02-2	A11011	MUFFLER ASSEMBLY	1
F02-3	A08747	NUT	2

F03




POS.	CODE	DESCRIPTION	QTY
F03-1	A11249	FUEL TANK	1
F03-2	A11234	FUEL STRAINER	1
F03-3	A11333	FUEL TANK COVER	1
F03-4	A08502	BOLT	1
F03-5	A08506	NUT	2
F03-6	A09934	FUEL TANK OIL OUTLET	1
F03-7	A08816	COLLAR	2
F03-8	A13080	FUEL TUBE	1

F04



POS.	CODE	DESCRIPTION	QTY
F04-1	A11017	NUT	4
F04-2	A08600	BOLT	2
F04-3	A10693	BOLT	2
F04-4	A09945	WASHER	2
F04-5	A10690	BOLT	4
F04-6	A08506	NUT	4
F04-7	A11334	ENGINE FRAME SHOCK ABSORPTION SEAT	4
F04-8	A11159	SCREW	3
F04-9	A10822	ENGINE FRAME DECORATED PLATE	1
F04-10	A11243	SWITCH	1
F04-11	A11299	STOP ENGINE WIRE	1
F04-12	A10847	ENGINE FRAME ASSEMBLY	1

F61



POS.	CODE	DESCRIPTION	QTY
F61-1	A10691	BOLT	4
F61-2	A11027	WATER OUTLET	1
F61-3	A10907	OUTLET GASKET	1
F61-4	A11096	PUMP BODY	1
F61-5	A05659	BOLT	3
F61-6	A10692	BOLT	4
F61-7	A10694	BOLT	4
F61-8	A10857	WASHER	5
F61-9	A10990	WATER PUMP JOINT	1
F61-10	A11000	GENERAL FLAT KEY	1
F61-11	A10695	BOLT	1
F61-12	A10813	WATER PUMP JOINT CUSHION	1
F61-13	A11038	CYLINDRICAL PIN	2
F61-14	A10945	WATER PUMP IMPELLER	1
F61-15	A10743	WHORL CASE	1
F61-16	A11112	WHORL CASE SEALING RIGN	1
F61-17	A11161	MECHANISM SEAL	1
F61-18	A11177	PORCELAIN SEAL	1
F61-19	A11134	IMPELLER SEAL RING	1
F61-20	A11292	SCREW PLUG WASHER	2
F61-21	A11070	THREAD PLUG	2
F61-22	A10896	INLET WATER GASKET	1
F61-23	A10954	WATER INLET	1
F61-24	A11086	WATER PUMP ASSEMBLY	1
F61-25	A10934	HOSE HOOP	3
F61-26	A10788	FILTER COVER	1
F61-27	A10833	FILTER	1
F61-28	A10963	HOSE INTERFACE	2
F61-29	A11123	HOSE JOINT SEAL RING	2
F61-30	A10977	HOSE JOINT	2