



**E01**




POS.	CODE	DESCRIPTION	QTY
E01-1	A12698	CRANKCASE	1
E01-2	A08704	OIL SEAL 35X25X7	1
E01-3	A08545	RUBBER PLUG	1
E01-4	A08546	FLAT WASHER	2
E01-5	A09104	DRAIN PLUG BOLT	2
E01-6	A08547	GOVERNOR ARM	1
E01-7	A08951	COTTER PIN	1
E01-8	A08548	FLAT WASHER	1
E01-9	A08924	WIRE CLIP	1

**E02**




POS.	CODE	DESCRIPTION	QTY
E02-1	A12668	CRANKCASE COVER	1
E02-2	A08305	CRANKCASE GASKET	1
E02-3	A10507	ENGINE OIL PLUG	1
E02-4	A10508	OIL DIPSTICK	1
E02-5	A08550	POSITION PIN	2
E02-6	A08551	BOLT	7
E02-7	A08552	BALL BEARING 6207	1
E02-8	A08730	GOVERNOR GEAR	1
E02-9	A08704	OIL SEAL 35X52X7	1
E02-10	A08549	BALL BEARING 6202	1

**E03**




POS.	CODE	DESCRIPTION	QTY
E03-1	A08306	CYLINDER HEAD GASKET	1
E03-2	A08307	CYLINDER HEAD COVER	1
E03-3	A08308	CYLINDER HEAD COVER GASKET	1
E03-4	A12703	BREATHER TUBE	1
E03-5	A08309	CYLINDER HEAD COVER BOLT	1
E03-6	A08310	CYLINDER HEAD COVER BOLT GASKET& WASHER	1
E03-7	A12684	STUD BOLT	2
E03-8	A10517	STUD BOLT	2
E03-9	A08557	POSITION PIN	2
E03-10	A08311	CYLINDER HEAD BOLT	4
E03-11	A08940	SPARK PLUG	1
E03-12	A08312	CYLINDER HEAD	1

**E04**




POS.	CODE	DESCRIPTION	QTY
E04-1	A12699	CRANKSHAFT ASSEMBLY	1
E04-4	A08422	BALANCING SHAFT	1

**E05**




POS.	CODE	DESCRIPTION	QTY
E05-1	A08410	PISTON PIN CLIP	2
E05-2	A08313	PISTON	1
E05-3	A08314	PISTON PIN	1
E05-4	A08315	CONNECTING ROD ASSEMBLY	1
E05-5	A08411	PISTON RING SET	1

**E06**




POS.	CODE	DESCRIPTION	QTY
E06-1	A08443	CAMSHAFT ASSEMBLY	1
E06-4	A08316	VALVES SET	1
E06-5	A08317	VALVE SPRING	2
E06-6	A08318	EXHAUST VALVE RETAINER	1
E06-7	A08319	VALVE ROTATOR	1
E06-8	A08320	SEAL GUIDE	1
E06-9	A08321	VALVE SPRING SEAT	1
E06-10	A08444	VALVE TAPPET	2
E06-11	A08430	VALVE LIFTER	2
E06-12	A08972	LIFTER STOPPER PLATE	1
E06-13	A08459	ROCKSHAFT BOLT	2
E06-14	A08463	ROCKER VALVE	2
E06-15	A08461	VALVE ADJUSTING NUT	2
E06-16	A08462	VALVE LOCK NUT	2
E06-17	A08322	VALVE SPRING RETAINER	1

**E07**



POS.	CODE	DESCRIPTION	QTY
E07-1	A08613	BOLT	3
E07-2	A12717	RECOIL STARTER ASSEMBLY	1


**E08**



POS.	CODE	DESCRIPTION	QTY
E08-1	A08656	SHROUD	1
E08-2	A08559	CYLINDER BODY SHROUD	1
E08-3	A08968	BOLT	1
E08-4	A08968	BOLT	5
E08-6	A10535	WIRE CLIP	1
E08-8	A09922	STOP ENGINE SWITCH GROUNDING WIRE	1




**E09**




POS.	CODE	DESCRIPTION	QTY
E09-1	A12669	CARBURETOR ASSEMBLY	1
E09-2	A10537	AIR CLEANER SEAL GASKET	1
E09-3	A08472	CARBURETOR SEAL GASKET	1
E09-4	A08480	CARBURETOR INSULATOR PLATE	1
E09-5	A08562	INLET GASKET	1

**E10**




POS.	CODE	DESCRIPTION	QTY
E10-1	A08431	FLYWHEEL NUT	1
E10-2	A08564	STARTER PULLEY	1
E10-3	A08657	IMPELLER	1
E10-4	A08433	FLYWHEEL	1
E10-5	A08937	BOLT	2
E10-6	A12656	IGNITION COIL	1
E10-7	A12688	CHARGE COIL	1
E10-8	A08937	BOLT	2
E10-9	A08494	BOLT	1
E10-10	A08658	CHARGE COIL CLAMP	1

**E11**




POS.	CODE	DESCRIPTION	QTY
E11-1	A12701	THROTTLE CONTROL ASSEMBLY	1
E11-2	A08568	THROTTLE VALVE RETURNING SPRING	1
E11-3	A08569	GOVERNOR ROD	1
E11-4	A12654	GOVERNOR SPRING	1
E11-5	A08571	GOVERNOR BRACKET	1
E11-6	A08968	BOLT	2
E11-7	A08506	HEXAGON NUT WITH FLANGE	1
E11-8	A08505	GOVERNOR SUPPORT BOLT	1

**F01**




POS.	CODE	DESCRIPTION	QTY
F01-1	A08506	HEXAGON NUT WITH FLANGE	2
F01-2	A08767	BOLT	1
F01-3	A12709	AIR CLEANER	1

**F02**




POS.	CODE	DESCRIPTION	QTY
F02-1	A10549	MUFFLER GASKET	1
F02-2	A10550	EXHAUST PIPE	1
F02-3	A08663	EXHAUST OUTLET GASKET	1
F02-4	A08520	NUT	5
F02-5	A12655	MUFFLER ASSEMBLY	2
F02-6	A12666	MUFFLER COVER	1

**F03**




POS.	CODE	DESCRIPTION	QTY
F03-1	A12653	FUEL TANK	1
F03-2	A09932	FUEL STRAINER	1
F03-3	A12708	FUEL TANK COVER	1
F03-4	A09934	FUEL TANK OIL OUTLET	1
F03-5	A08816	COLLAR	2
F03-6	A12704	FUEL TUBE	1
F03-7	A08520	HEXAGON NUT WITH FLANGE	2
F03-8	A10693	BOLT	2

# F12



POS.	CODE	DESCRIPTION	QTY
F12-1	A12679	STARTING MOTOR ASSEMBLY	1
F12-2	A08600	BOLT	2


**W01**



POS.	CODE	DESCRIPTION	QTY
W01-1	A12670	ENGINE	1
W01-2	A05750	HEXAGON NUT	7
W01-3	A09938	FLAT WASHER	7
W01-4	A05768	FLAT WASHER	7
W01-5	A12690	GUARD	1
W01-6	A12634	ENGINE CONNETING SEAT	1
W01-7	A11350	BOLT	3
W01-8	A10356	BOLT	4




# W02-1




POS.	CODE	DESCRIPTION	QTY
W02-1	A10558	ENGINE SEAL GASKET	1
W02-2	A10564	FLANGE	1
W02-3	A10571	PRESSURE RELIEF BOLT	1
W02-4	A10282	FLAT WASHER	8
W02-5	A10678	SCREW	8
W02-6	A05768	FLAT WASHER	4
W02-7	A09938	FLAT WASHER	4
W02-8	A11350	BOLT	2
W02-9	A05749	HEXAGONAL HEAD BOLT	2
W02-10	A10559	FLANGE SEAL GASKET	1
W02-11	A11349	BALL BEARING 6007	1

# W02-2




POS.	CODE	DESCRIPTION	QTY
W02-12	A10560	CLUTCH	1
W02-13	A10621	HEXAGONAL HEAD BOLT	1
W02-14	A10282	FLAT WASHER	1
W02-15	A09945	FLAT WASHER	1
W02-16	A10561	STILL RING	2
W02-17	A10562	MAIN AXLE	1
W02-18	A10563	STOPPER SPRING	2
W02-19	A10257	STEEL BALL	4
W02-20	A10565	DUPLICATE GEAR	1
W02-21	A10566	O-TYPE RUBBER SEAL RING	2
W02-22	A10339	COTTER PIN	2
W02-23	A10567	STILL RING	1
W02-24	A10568	FLAT WASHER	1
W02-25	A04760	BALL BEARING 6202	1
W02-26	A10569	COUNTERSHAFT BEVEL GEAR	1
W02-27	A10263	GENERAL FLAT KEY	1
W02-28	A10565	DUPLICATE GEAR	1
W02-29	A10570	NEEDLE BEARING	2
W02-31	A10572	BUSH	1
W02-32	A10573	THRUST BALL BEARING	1
W02-33	A10574	COUNTERSHAFT	1
W02-34	A10575	PIN	2
W02-35	A10340	HEXAGON SLOTTED NUT	1
W02-36	A10268	FLAT WASHER	1
W02-37	A10269	REVERSE GEAR STOP COLLAR	1
W02-38	A10270	REVERSE GEAR SPRING	1
W02-39	A10576	FLAT WASHER	1
W02-40	A10577	DUPLICATE GEAR	1
W02-41	A10578	REVERSE GEAR COLLAR	1
W02-42	A10579	REVERSE GEAR SHAFT	1
W02-43	A10277	O-TYPE RUBBER SEAL RING	1

# W02-3




POS.	CODE	DESCRIPTION	QTY
W02-44	A10580	SHIFT ARM	1
W02-45	A10581	PIN SHAFT	1
W02-46	A10287	COTTER PIN	1
W02-47	A10582	O-TYPE RUBBER SEAL RING	6
W02-48	A10583	BUSH	1
W02-49	A10584	SHIFTS FORK	1
W02-50	A10585	SHIFTS FORK	1
W02-51	A10586	OIL DIPSTICK	1
W02-52	A10587	CABLE BASE	1
W02-53	A10588	BOLT	1
W02-54	A10589	SHIFTS FORK	1
W02-55	A10590	PIN SHAFT	1
W02-56	A10287	COTTER PIN	1
W02-57	A10591	SHIFTS FORK	1
W02-58	A10592	BUSH	3
W02-59	A10593	SHIFTS FORK	1
W02-60	A10594	CIRCLIP FOR SHAFT	1
W02-61	A10595	CABLE BASE	1
W02-62	A10596	SHIFTS FORK	1
W02-63	A10597	SLOTTED FLAT END SET SCREWS	1

**W03**




POS.	CODE	DESCRIPTION	QTY
W03-1	A12706	BOX BODY TRANSMISSION	1
W03-2	A10608	BALL BEARING	1
W03-3	A10609	BUSH	1
W03-4	A10610	LOCK WASHER FOR ROUND NUTS	1
W03-5	A10611	SMALL ROUND NUT	1
W03-6	A10612	FLAT KEY SET	1
W03-7	A10263	FLAT KEY	1
W03-8	A10613	GASKET	1
W03-9	A10282	FLAT WASHER	1
W03-10	A10621	HEXAGONAL HEAD BOLT	1
W03-11	A10599	O-TYPE RUBBER SEAL RING	1
W03-12	A10600	MAIN SHAFT GLAND	1
W03-13	A10601	OIL SEAL	1
W03-14	A10602	MAIN SHAFT SAFETY GUARD	1
W03-15	A10603	FLAT WASHER	4
W03-16	A08687	HEXAGONAL HEAD BOLT	4
W03-17	A10605	FLAT WASHER	1
W03-18	A10858	FLAT WASHER	1
W03-19	A10607	HEXAGONAL HEAD BOLT	1
W03-20	A05768	FLAT WASHER	1
W03-21	A09938	STANDARD SPRING WASHER	1
W03-22	A11347	HEXAGONAL HEAD BOLT	1

**W04**




POS.	CODE	DESCRIPTION	QTY
W04-1	A10614	HEXAGONAL FIXING SLEEVE	2
W04-2	A10621	HEXAGONAL HEAD BOLT	2
W04-3	A10629	OUTPUT SHAFT DUST-PROOF COVER	2
W04-4	A10632	OIL SEAL 45X62X8	4
W04-5	A10633	OUTPUT SHAFT	1
W04-6	A10634	BALL BEARING 6009	1
W04-7	A12689	BOX BODY TRANSMISSION	1
W04-8	A10636	OUTPUT SHAFT SPACER BUSH	1
W04-9	A10637	HEXAGONAL OUTPUT SHAFT SLEEVE	1
W04-10	A10615	TRANSPORTATION BEVEL GEAR	1
W04-11	A10616	TAPERED ROLLER BEARINGS	1
W04-12	A10617	TRANSPORTATION BOX END COVER SEALING GASKET	1
W04-13	A12667	TRANSMISSION BOX COVER	1
W04-14	A10325	FLAT WASHER	10
W04-15	A10326	FLAT WASHER	10
W04-16	A05773	HEXAGONAL HEAD BOLT	6
W04-17	A10619	HEXAGONAL HEAD BOLT	4
W04-18	A10347	O-TYPE RUBBER SEAL RING	1
W04-19	A10620	DRAIN PLUG BOLT	1
W04-20	A10622	HEXAGON NUT	4
W04-21	A10623	SEAL GASKET	1
W04-22	A10624	SEAL GASKET	1
W04-23	A10625	NUT	1
W04-24	A10342	FLAT WASHER	2
W04-25	A10626	DRIVEN BEVEL GEAR	1
W04-26	A10627	TAPERED ROLLER BEARING 30206	1

**W04**



POS.	CODE	DESCRIPTION	QTY
W04-27	A10628	TRANSPORTATION BEVEL GEAR SHAFT	1
W04-28	A10346	TAPERED ROLLER BEARING 30204	1
W04-29	A10339	COTTER PIN	1
W04-30	A10630	FLAT WASHER	1
W04-31	A10631	FLAT WASHER	1


**F19**



POS.	CODE	DESCRIPTION	QTY
F19-1	A12695	TRANSMISSION BOX ASSEMBLY	1




**W05**



POS.	CODE	DESCRIPTION	QTY
W05-1	A05748	SOCKET	1
W05-2	A12680	GEAR LEVER	1
W05-3	A09965	LOCK HANDLE	1
W05-4	A09964	WIRE CLIP	2
W05-5	A09966	FLAT WASHER	1
W05-6	A10646	FLAT WASHER	1
W05-7	A10305	HANDLE TUBE ASSY	1
W05-8	A10647	REVERSE GEAR CABLE	1
W05-9	A12678	CLUTCH HANDLE	1
W05-10	A10311	PIN SHAFT	1
W05-11	A10289	PIN SHAFT	1
W05-12	A10287	COTTER PIN	2
W05-13	A10312	REVERSE GEAR STOPPER V	1
W05-14	A10638	THROTTLE COCK	1
W05-15	A09942	HANDLE RUBBER SLEEVE	2
W05-16	A09943	PANEL	1
W05-17	A09944	NUT	1
W05-18	A09945	FLAT WASHER	1
W05-19	A10680	HEXAGONAL HEAD BOLT	1
W05-20	A10314	HANDLE TUBE	1
W05-21	A12676	FORWARD CLUTCH HANDLE	1
W05-22	A04813	BOLT	2
W05-26	A10681	SCREW	2
W05-27	A11345	SCREW	2
W05-28	A13105	FLAT WASHER	4
W05-29	A11344	HEXAGONAL HEAD BOLT	1
W05-30	A10641	LOCK HANDLE	1
W05-31	A10642	FLAT WASHER	1
W05-32	A10643	TOOTH DISK PLATE	1




**W05**




POS.	CODE	DESCRIPTION	QTY
W05-33	A10644	ARMREST ASSEMBLY	1
W05-34	A10645	BOLT	4
W05-35	A05768	FLAT WASHER	4
W05-36	A09938	FLAT WASHER	4
W05-37	A05750	HEXAGON NUT	4
W05-39	A12651	STOP ENGINE SWITCH	1
W05-40	A12633	FIXING PLATE	1
W05-41	A12641	BOLT	2
W05-42	A05751	NUT	2
W05-43	A12652	STARTING SWITCH	1
W05-44	A12663	MAIN CABLE	1
W05-44	A12663	MAIN CABLE	1

# W06




POS.	CODE	DESCRIPTION	QTY
W06-1	A11347	HEXAGONAL HEAD BOLT	8
W06-2	A09938	FLAT WASHER	8
W06-3	A05750	HEXAGON NUT	8
W06-4	A10366	TRANSPORTATION WHEEL	1
W06-5	A10367	TRANSPORTATION WHEEL	1
W06-6	A10648	REAR WHEEL SHAFT	2

**W07**




POS.	CODE	DESCRIPTION	QTY
W07-1	A04813	BOLT	12
W07-2	A05751	BOLT	12
W07-3	A10653	MINI-TILLER FENDER	1
W07-4	A10654	MINI-TILLER FENDER	1
W07-5	A10655	MINI-TILLER FENDER	1
W07-6	A10656	MINI-TILLER FENDER	1
W07-7	A10657	FRONT FENDER SUPPORT	1
W07-8	A10658	FRONT FENDER SUPPORT	1
W07-9	A10659	FRONT FENDER SUPPORT	1
W07-10	A10649	FRONT FENDER SUPPORT	1
W07-11	A05768	FLAT WASHER	3
W07-12	A09938	STANDARD SPRING WASHER	3
W07-13	A05750	HEXAGON NUT	5
W07-14	A10650	TRAILING BODY	1
W07-15	A05680	HEXAGONAL HEAD BOLT	3
W07-16	A10357	PIN SHAFT	1
W07-17	A05679	R PIN	1
W07-18	A10651	CONNECTION FRAME	1
W07-19	A05707	DAMPING ARM	1
W07-20	A06140	PIN SHAFT	1
W07-21	A05748	R PIN	1
W07-22	A11350	HEXAGONAL HEAD BOLT	2
W07-23	A04783	BOLT	4
W07-24	A10652	BOLT	1
W07-25	A04793	HEXAGON NUT WITH FLANGE	1
W07-26	A05640	WASHER	12
W07-27	A09945	FLAT WASHER	4

# W08




POS.	CODE	DESCRIPTION	QTY
W08-1	A10664	CYLINDER	1
W08-2	A12638	CYLINDER	1
W08-3	A10665	CYLINDER	1
W08-4	A10662	PIN SHAFT	4
W08-5	A05748	SOCKET	4
W08-6	A10354	HEXAGONAL HEAD BOLT	20
W08-7	A05750	HEXAGON NUT	20
W08-8	A09938	FLAT WASHER	20
W08-9	A05906	ROTARY BLADE	10
W08-10	A05954	ROTARY BLADE	10
W08-11	A10660	TRIMMING WHEEL	1

**W09**



POS.	CODE	DESCRIPTION	QTY
W09-1	A10664	CYLINDER	1
W09-2	A12638	CYLINDER	1
W09-3	A10665	CYLINDER	1
W09-4	A10662	PIN SHAFT	4
W09-5	A05748	SOCKET	4
W09-6	A10354	HEXAGONAL HEAD BOLT	20
W09-7	A05750	HEXAGON NUT	20
W09-8	A09938	FLAT WASHER	20
W09-9	A05906	ROTARY BLADE	10
W09-10	A05954	ROTARY BLADE	10
W09-11	A10660	TRIMMING WHEEL	1

# W10



POS.	CODE	DESCRIPTION	QTY
W10-1	A12673	BATTERY CLAMP	1
W10-2	A12647	BOLT	2
W10-3	A04783	BOLT	1
W10-4	A12659	MOTOR WIRES	1
W10-5	A12660	MOTOR WIRES	1
W10-6	A12682	BATTERY	2
W10-7	A12714	BATTERY GASKET	3
W10-8	A12657	BATTERY CASE	1
W10-9	A05751	LOCK NUT	2
W10-10	A05751	LOCK NUT	2