



TABLE 1



POS.	CODE	DESCRIPTION	QTY
1	A12496	PUMP	1
2	A12497	KEY	1
3	A12498	PUMP FIX BOLT	4
4	A12499	SPRING WASHER	4
5	A12500	PLAIN WASHER	4
6	47233	ENGINE*	1
7	A12501	NUT	8
8	A12502	SPRING WASHER	8
9	A12503	PLAIN WASHER	8
SET 1 (10-12)	A12504	GUN HOLDER AND HOSE HOOK	1
13	A12424	GROMMET	5
14	48528	SET NOZZLES	1
15	A12506	DECAL	1
16.1	A12507	FRAME	1
16.2	A13227	HANDLE	1
SET 2 (17-19)	A12508	RUBBER FOOT	2
20	A12509	ENGINE FIX BOLT	4
21	A12510	SPRING WASHER	4
22	A12511	PLAIN WASHER	4
SET 3 (23-27, 29, 30)	A12512	AXLE ASSEMBLY	2
28	A12513	WHEEL	2
31	47504	LANCE	1
32	47501	GUN	1
33	47508	PRESSURE HOSE 15m	1


*ENGINE'S SPARE PARTS IN DETAILED DRAWING (47233)

PUMP




POS.	CODE	DESCRIPTION	QTY
1	A12514	CRANKCASE COVER BOLT	6
2	A12453	OIL DRAIN PLUG	1
3	A12482	O-RING (14.2X1.9)	1
4	A12443	VENTED OIL CAP	1
5	A12447	CRANKCASE COVER	1
6	A12454	CRANKCASE COVER GASKET	1
7	A12446	CRANKCASE	1
8	A12492	NEEDLE BEARING	1
9	A12485	O-RING (51.8X2.2)	1
10	A12515	FLANGE	1
11	A12516	FLANGE BOLT	4
12	A12517	OIL SEAL	1
13	A12518	CRANKSHAFT	1
14	A12478	BALL BEARING 6305	1
15	A12480	CLIP D25	1
16	A12486	O-RING (55.25X2.62)	1
17	A12479	CLIP D42	1
18	A12452	OIL LEVEL PLATE	1
19	A12451	OIL SIGHT GLASS	1
20	A12483	O-RING (38X1.8)	1
21	A12450	CRANKSHAFT COVER	1
22	A12475	BOLT M8X16	4
23	A12449	CONNECTING ROD	3
24	A12448	PIN	3
25	A12519	CERAMIC COATING PLUNGER	3
26	A12520	O-RING	3
27	A12521	OIL SEAL	3
28	A12522	LOCATING RING	3
29	A12489	O-RING (26.7X1.78)	3

PUMP



POS.	CODE	DESCRIPTION	QTY
30	A12523	LOW PRESSURE WATER SEAL	3
31	A12524	COMPRESSION RING	3
32	A12525	COMPRESSION FLAKE	3
33	A12526	HIGH PRESSURE WATER SEAL	3
34	A12527	SUPPORTING RING	3
35	A12528	MANIFOLD	1
SET 1 (36+37)	A12529	SET CHECKING VALVES	1
38	A12530	VALVE CAP O-RING	6
39	A12531	CHECKING VALVE CAP	6
40	A12532	MANIFOLD OUTLET PLUG	1
41	A12533	THERMAL RELIEF VALVE	1
42	A12534	WASHER	8
43	A12535	BOLT	8
SET 2 (44-51, 80)	A12444	PRESSURE REDUCER ASSEMBLY	1
52	A12457	VALVE SEAT	1
53	A12536	VALVE SEAT O-RING	1
54	A12537	UNLOADER VALVE HOUSING GASKET	1
55	A12538	DETERGENT INJECTOR FITTING	1
56	A12539	INJECTOR FITTING O-RING	1
57	A12540	INJECTOR FITTING BALL	1
58	A12541	INJECTOR FITTING SPRING	1
59	A12542	WATER OUTLET BANJO BOLT	1
60	A12543	O-RING	1
61	A12544	O-RING	1
62	A12545	UNLOADER VALVE HOUSING	1
63	A12490	O-RING	1
64	A12546	OUTLET CHECKING VALVE	1

PUMP



POS.	CODE	DESCRIPTION	QTY
65	A12459	OUTLET CHECKING VALVE SPRING	1
66	A12547	O-RING	2
67	A12548	QUICK DISCONNECT OUTLET FITTING	1
68	A12549	BYPASS HOUSING GASKET	1
69	A12550	WATER INLET BANJO BOLT	1
70	A12551	O-RING	1
71	A12552	BYPASS HOUSING	1
72	A12553	INLET CONNECTOR SWIVEL NUT	1
73	A12554	INLET CONNECTOR BODY	1
74	A12462	INLET CONNECTOR FILTER WASHER	1