


PARTS LIST

DEMOLITION HAMMER

BPH2200

Art# 017240




Use only BORMANN genuine parts as specified in the parts list for repair or replacement.
Check if your machine meets the applicable models listed below.
The contents described in the parts list may change due to improvement.



APPLICABLE:

March 2020



BPH2200 Fig. A



No#	Code	Description (EN)	QTY	Notes
1	0172400001	lock rod	1	
2	0172400002	round pin	1	
3	0172400003	o-ring18X8	2	
4	0172400004	headstrong	1	
5	0172400005	lock rod cover	1	
6	0172400006	spring	1	
7	0172400007	washer32*17*2	1	
8	0172400008	screwM12X75	6	
9	0172400009	washer12	6	
10	0172400010	headstrong spring	6	
11	0172400011	o-ring 83X2	1	
12	0172400012	ram hammer cover	1	
13	0172400013	ram hammer	1	
14	0172400014	o-ring71*2	1	
15	0172400015	o-ring31.5X5	1	
16	0172400016	"Aluminum muzzle "	1	
17	0172400017	big damping ring55*84*15	1	
18	0172400018	washer47*85*7	1	
19	0172400019	open mouth	1	
20	0172400020	big washer	2	
21	0172400021	small damping ring67*77.5*8	1	
22	0172400022	cylinder house	1	
23	0172400023	screwM10X45	4	
24	0172400024	spring washer	4	
25	0172400025	washer	4	
26	0172400026	o-ring	1	
27	0172400027	cylinder	1	
28	0172400028	o-ring	1	
29	0172400029	piston pin	1	
30	0172400030	piston	1	
31	0172400031	Y-ring	1	
32	0172400032	connecting rod	1	
33	0172400033	needle bearingNK22/20	1	
34	0172400034	needle bearing board	1	
35	0172400035	spring washer8	9	
36	0172400036	screwM8X30	4	
37	0172400037	motor house	1	
38	0172400038	oil gauge	1	
39	0172400039	O-ring	1	
40	0172400040	eccentric shaft	1	
41	0172400041	woodruff key4*6.5*16	2	
42	0172400042	screwM6X20	4	
43	0172400043	spring washer6	14	
44	0172400044	washer6	14	
45	0172400045	bearing seat	1	
46	0172400046	o-ring126X2	1	
47	0172400047	bearing6205-2RS	1	
48	0172400048	inner cover	1	
49	0172400049	front cap seal ring	1	
50	0172400050	oil seal	1	
51	0172400051	ring22*32*15.5	1	
52	0172400052	big gear	1	

No#	Code	Description (EN)	QTY	Notes
53	0172400053	ring22	1	
54	0172400054	bearing6302-2RZ	1	
55	0172400055	front cover	1	
56	0172400056	left handle	1	
57	0172400057	screwM6X22	4	
58	0172400058	screwM8X50	6	
59	0172400059	washer8	8	
60	0172400060	bearing6201-2RZ	2	
61	0172400061	middle gear36	1	
62	0172400062	screwM5X16	11	
63	0172400063	spring washer5	13	
64	0172400064	bearing board	1	
65	0172400065	bearing6001-2RZ	1	
66	0172400066	bearing6203-2RS	1	
67	0172400067	round pin5*14	2	
68	0172400068	rotor	1	
69	0172400069	screwST5X75	2	
70	0172400070	stator	1	
71	0172400071	tension spring	2	
72	0172400072	stator tank	1	
73	0172400073	left motor cover	1	
74	0172400074	screw M4*12	8	
75	0172400075	right motor cover	1	
76	0172400076	screw M4*10	2	
77	0172400077	chassis	1	
78	0172400078	screw M5*8	2	
79	0172400079	insulating bush	1	
80	0172400080	brush holder	2	
81	0172400081	brush	2	
82	0172400082	brush cover	2	
83	0172400083	brush holder pad	2	
84	0172400084	brush steel cover	2	
85	0172400085	spring washer4	8	
86	0172400086	screw M4*12	8	
87	0172400087	ring	1	
88	0172400088	oil core holder	1	
89	0172400089	oil core	1	
90	0172400090	paper	1	
91	0172400091	fuel tank cap	1	
92	0172400092	screwM6X55	6	
93	0172400093	screwST3.9X16	7	
94	0172400094	right handle cover	1	
95	0172400095	button	1	
96	0172400096	rubber blanket	1	
97	0172400097	switch	1	
98	0172400098	capacitance	1	
99	0172400099	right handle	1	
100	0172400100	cable board	1	
101	0172400101	cable	1	
102	0172400102	cable sheath	1	
103	0172400103	screwM6X25	2	
104	0172400104	side cover	1	